

# **User's Manual**

# **78K0/Kx2-L - Save It!**

## **Low power consumption 8-bit microcontroller Demonstration Kit**

---

- **The information in this document is current as of June, 2008. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC Electronics data sheets or data books, etc., for the most up-to-date specifications of NEC Electronics products. Not all products and/or types are available in every country. Please check with an NEC Electronics sales representative for availability and additional information.**
- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.
- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.
- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of a customer's equipment shall be done under the full responsibility of the customer. NEC Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.
- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.
- NEC Electronics products are classified into the following three quality grades: "Standard", "Special" and "Specific".  
 The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics product before using it in a particular application.  
 "Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.  
 "Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).  
 "Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

(Note)

(1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.

(2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

M8E 02. 11-1

**CAUTION**

This is a Test- and Measurement equipment with possibility to be significantly altered by user through hardware enhancements/modifications and/or test or application software. Thus, with respect to Council Directive 89/336/EEC (Directive on compliance with the EMC protection requirements), this equipment has no autonomous function. Consequently this equipment is not marked by the CE-symbol.

EEDT-ST-005-10

**CAUTION**

This equipment should be handled like a CMOS semiconductor device. The user must take all precautions to avoid build-up of static electricity while working with this equipment. All test and measurement tool including the workbench must be grounded. The user/operator must be grounded using the wrist strap. The connectors and/or device pins should not be touched with bare hands.

EEDT-ST-004-10

**For customers in the European Union only**

Redemption of Waste Electrical and Electronic Equipment (WEEE) in accordance with legal regulations applicable in the European Union only: This equipment (including all accessories) is not intended for household use. After use the equipment cannot be disposed of as household waste. NEC Electronics (Europe) GmbH offers to take back the equipment. All you need to do is register at <http://www.eu.necel.com/weee>

## Regional Information

Some information contained in this document may vary from country to country. Before using any NEC product in your application, please contact the NEC office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- Ordering information
- Product release schedule
- Availability of related technical literature
- Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

### **NEC Electronics Inc. (U.S.)**

Santa Clara, California  
Tel: 408-588-6000  
800-366-9782  
Fax: 408-588-6130  
800-729-9288

### **NEC Electronics Hong Kong Ltd.**

Hong Kong  
Tel: 2886-9318  
Fax: 2886-9022/9044

### **NEC Electronics (Europe) GmbH**

Duesseldorf, Germany  
Tel: 0211-65 03 0  
Fax: 0211-65 03 1327

### **NEC Electronics Hong Kong Ltd.**

Seoul Branch  
Seoul, Korea  
Tel: 02-528-0303  
Fax: 02-528-4411

### **Sucursal en España**

Madrid, Spain  
Tel: 091- 504 27 87  
Fax: 091- 504 28 60

### **NEC Electronics Singapore Pte. Ltd.**

Singapore  
Tel: 65-6253-8311  
Fax: 65-6250-3583

### **Succursale Française**

Vélizy-Villacoublay, France  
Tel: 01-30-67 58 00  
Fax: 01-30-67 58 99

### **NEC Electronics Taiwan Ltd.**

Taipei, Taiwan  
Tel: 02-2719-2377  
Fax: 02-2719-5951

### **Filiale Italiana**

Milano, Italy  
Tel: 02-66 75 41  
Fax: 02-66 75 42 99

### **NEC do Brasil S.A.**

Electron Devices Division  
Guarulhos, Brasil  
Tel: 55-11-6465-6810  
Fax: 55-11-6465-6829

### **Branch The Netherlands**

Eindhoven, The Netherlands  
Tel: 040-244 58 45  
Fax: 040-244 45 80

### **Branch Sweden**

Taeby, Sweden  
Tel: 08-63 80 820  
Fax: 08-63 80 388

### **United Kingdom Branch**

Milton Keynes, UK  
Tel: 01908-691-133  
Fax: 01908-670-290

**Revision History**

<b>Date</b>	<b>Revision</b>	<b>Chapter</b>	<b>Description</b>
02.01.2010	V1.00	---	First release

## Table of Contents

1. Introduction .....	10
1.1 Package contents .....	10
1.2 Features .....	10
1.3 System requirements .....	11
1.4 Trademarks .....	11
2. 78K0/Kx2-L – Save It! Components .....	12
2.1 Operation mode settings .....	12
2.2 SW1 .....	13
2.3 SW2 .....	13
2.4 SW3 .....	13
2.5 SW4 (Reset switch) .....	13
2.6 SW5 (INTP1) .....	13
2.7 SW6 (INTP4) .....	14
2.8 JP1 .....	14
2.9 JP2 .....	14
2.10 Q4 (illuminance sensor) .....	14
2.11 U8, U10 (7 segment LED) .....	14
2.12 LED1 (power LED) .....	15
2.13 Universal area .....	15
2.14 Minicube2 connector .....	15
3. 78K0/Kx2-L – Save It! Solder-short pads .....	16
4. 78K0/Kx2-L – Save It! system configuration .....	17
4.1 78K0/Kx2-L – Save It! .....	17
4.2 Host computer .....	17
4.3 Power supply .....	17
5. 78K0/Kx2-L – Save It! installation and operation .....	18
5.1 Getting started .....	18
5.2 CD-ROM contents .....	18
6. Hardware installation .....	19
7. Software installation .....	20
7.1 TK-78K0KC2L demonstration program installation .....	20
7.2 IAR Systems Embedded Workbench for 78K installation .....	21
7.3 IAR Systems visualSTATE Installation .....	22
7.4 Applilet3 for 78K0/Kx2-L .....	22
7.5 WriteEZ5 installation .....	22

<b>7.6</b>	<b>Sample projects .....</b>	<b>22</b>
<b>7.7</b>	<b>USB Driver Installation .....</b>	<b>22</b>
7.7.1	Installation on Windows 2000 .....	22
7.7.2	Installation on Windows XP.....	26
<b>7.8</b>	<b>Confirmation of USB Driver Installation .....</b>	<b>29</b>
<b>8.</b>	<b>Flash Programmer WriteEZ5.....</b>	<b>30</b>
<b>8.1</b>	<b>Device Setup.....</b>	<b>30</b>
<b>8.2</b>	<b>Using WriteEZ5.....</b>	<b>31</b>
<b>9.</b>	<b>Demo application using the TK-78K0/KC2L demonstration program.....</b>	<b>32</b>
<b>10.</b>	<b>Applilet3 for 78K0/Kx2-L .....</b>	<b>34</b>
<b>10.1</b>	<b>Overview .....</b>	<b>34</b>
<b>10.2</b>	<b>Applilet3 for 78K0/Kx2-L sample application.....</b>	<b>34</b>
10.2.1	Clock and On-chip debug settings .....	35
10.2.2	Timer setting.....	35
10.2.3	RTC setting .....	36
10.2.4	Interrupt setting .....	37
10.2.5	Port setting .....	38
<b>11.</b>	<b>IAR Embedded Workbench 78K0/Kx2-L – Save It! sample project.....</b>	<b>39</b>
<b>11.1</b>	<b>Hardware setup .....</b>	<b>39</b>
<b>11.2</b>	<b>Loading the 78K0/Kx2-L Save It! sample project.....</b>	<b>39</b>
<b>11.3</b>	<b>Running the application .....</b>	<b>43</b>
11.3.1	Count mode.....	43
11.3.2	Blink mode.....	43
11.3.3	Spinning mode .....	44
<b>12.</b>	<b>IAR visualSTATE 78K0/Kx2-L – Save It! sample project .....</b>	<b>45</b>
<b>12.1</b>	<b>Hardware setup .....</b>	<b>45</b>
<b>12.2</b>	<b>Functionality of the sample project .....</b>	<b>45</b>
<b>12.3</b>	<b>Running the sample project.....</b>	<b>46</b>
<b>12.4</b>	<b>Debug the 78K0/Kx2-L – Save It! visualSTATE sample project .....</b>	<b>48</b>
<b>13.</b>	<b>Cables .....</b>	<b>49</b>
<b>13.1</b>	<b>USB interface cable (Mini-B type) .....</b>	<b>49</b>
<b>14.</b>	<b>Schematics .....</b>	<b>50</b>

## List of Figures

Figure 1: 78K0/Kx2-L – Save It! components .....	12
Figure 2: 78K0/Kx2-L – Save It! 7 segment LEDs structure .....	15
Figure 3: 78K0/Kx2-L – Save It! 7 segment LED port pin connection.....	15
Figure 4: 78K0/Kx2-L – Save It! MiniCube2 connector.....	15
Figure 5: 78K0/Kx2-L starter kit Solder-short pads .....	16
Figure 6: 78K0/Kx2-L- Save It! system configuration.....	17
Figure 7: 78K0/Kx2-L – Save It! CD-ROM contents.....	18
Figure 8: 78K0/Kx2-L – Save It! CRROM autorun.exe .....	20
Figure 9: IAR Systems Installation screen .....	21
Figure 10: Found New Hardware Wizard (Windows 2000).....	23
Figure 11: Search Method (Windows 2000).....	23
Figure 12: Driver File Location (Windows 2000).....	24
Figure 13: Address Specification 1 (Windows 2000) .....	24
Figure 14: Address Specification 2 (Windows 2000) .....	25
Figure 15: Address Specification 3 (Windows 2000) .....	25
Figure 16: Driver File Search (Windows 2000) .....	25
Figure 17: USB Driver Installation Completion (Windows 2000) .....	26
Figure 18: Found New Hardware Wizard 1 (Windows XP).....	26
Figure 19: Found New Hardware Wizard 2 (Windows XP).....	27
Figure 20: Search Location Specification 1 (Windows XP).....	27
Figure 21: Search Location Specification 2 (Windows XP).....	28
Figure 22: Windows XP Logo Testing (Windows XP).....	28
Figure 23: USB Driver Installation Completion (Windows XP).....	29
Figure 24: Windows Device Manager .....	29
Figure 25: WriteEZ5 Startup.....	30
Figure 26: WriteEZ5 Device Setup Dialogue .....	30
Figure 27: WriteEZ5 Device Menu .....	31
Figure 28: TK-78K0RKE3L demonstration program .....	32
Figure 29: Applilet3 for 78K0/Kx2-L main window .....	34
Figure 30: Applilet3 for 78K0/Kx2-L On-chip debug window .....	35
Figure 31: Applilet3 for 78K0/Kx2-L Timer Function select.....	35
Figure 32: Applilet3 for 78K0/Kx2-L Timer TM00 settings .....	36
Figure 33: Applilet3 for 78K0/Kx2-L RTC settings .....	36
Figure 34: Applilet3 for 78K0/Kx2-L RTCl settings .....	37
Figure 35: Applilet3 for 78K0/Kx2-L External Interrupt settings .....	37
Figure 36: IAR Embedded Workbench Startup window.....	39
Figure 37: IAR Embedded Workbench Main IDE window .....	40
Figure 38: IAR Embedded Workbench Debugger Options .....	41
Figure 39: Embedded Workbench Linker Configuration .....	41
Figure 40: IAR Embedded Workbench MINICUBE2 settings .....	42
Figure 41: IAR C-SPY debugger .....	43
Figure 42: IAR visualSTATE navigator.....	46
Figure 43: IAR visualSTATE designer.....	47
Figure 44: IAR Embedded Workbench visualSTATE sample project.....	48
Figure 45: USB interface cable (Mini-B type).....	49



**List of Tables**

Table 1: 78K0/Kx2-L – Save It! Switch and Jumper settings .....	12
Table 2: SW1 modes .....	13
Table 3: SW2 modes .....	13
Table 4: SW3 modes .....	13
Table 5: JP1 settings .....	14
Table 6: JP2 settings .....	14
Table 7: 7 segment LED port values .....	15
Table 8: 78K0/Kx2-L – Save it! Solder short pads .....	16
Table 10: WriteEZ5 action buttons .....	31
Table 11: IAR EWB 78K0/Kx2-L – Save It! sample project hardware setup .....	39
Table 12: IAR VS 78K0/Kx2-L – Save It! Sample project hardware setup .....	45

## 1. Introduction

The *78K0/Kx2-L - Save It!* demonstration Kit shows the system development possibilities using a NEC low power consumption microcontroller of the 78K0/Kx2-L microcontroller family.

A preprogrammed sample project, which is written to work with the TK-78K0/KC2L demo PC graphical user interface, provided on the CD-ROM, shows the current consumption in the different operating modes.

Furthermore an Applilet3 for 78K0/Kx2-L, IAR Embedded Workbench for 78K and IAR visualSTATE sample projects for the 78K0/Kx2-L can be found on the CD-ROM.

### 1.1 Package contents

- TK-78K0/KC2L board
- USB cable
- CD-ROM containing the TK-78K0/KC2L GUI, Applilet3 for 78K0/Kx2-L, an evaluation copy of the IAR Embedded Workbench for 78K with 4Kbyte code size limitation and IAR visualSTATE, as well as device drivers, sample programs and Microsoft .net

Please verify that you have received all parts listed in the package contents list attached to the *78K0/Kx2-L - Save It!* demonstration kit package. If any part is missing or seems to be damaged, please contact the dealer from whom you received your *78K0/Kx2-L - Save It!*

### 1.2 Features

- NEC Electronics  $\mu$ PD78F0588 low power consumption general purpose NEC 8-bit 78K0 MCU
- NEC Electronics  $\mu$ PD78F0730 MCU with on-chip USB interface
- 2 latched 7-segment LEDs
- Low current consumption modes demo application with GUI for the Host PC
- Applilet3 for 78K0/Kx2-L peripheral driver configurator
- On-Board debug function (TK-78K0 debugging)  
The *78K0/Kx2-L - Save It!* supports an On-Board debug function by using the IAR C-SPY debugger without a need of additional debug hardware. It allows FLASH downloading and standard debug functions like code execution, single stepping, breakpoints, memory manipulation etc.
- Power supply by USB interface or via external power supply (power supply connector not mounted)
- The IAR Embedded Workbench for 78K is included. This package is restricted in such that maximum program code size is limited to 4 Kbyte.
- IAR visualSTATE demo, a package of integrated tools for developing, testing, and implementing embedded applications based on state chart diagrams.
- Full documentation is included for the NEC 78K078F0588 microcontroller, NEC 78K0 78F0730 microcontroller, IAR Systems Embedded Workbench and IAR Systems visualSTATE.

**The *78K0/Kx2-L – Save It!* is not intended for code development. NEC does not allow and does not support in any way any attempt to use *78K0/Kx2-L – Save It!* in a commercial or technical product.**

### 1.3 System requirements

<b>HOST PC</b>	<p>A PC supporting Windows 2000, Windows XP or Windows Vista is required for the IAR Systems Embedded Workbench demo-version.</p> <p>A Pentium processor with at least 1 GHz CPU performance, with at least 256 Mbytes of RAM, allowing you to fully utilize and take advantage of the product features. 500 Mbytes of free disk space and an additional 10 Mbytes of free disk space on the Windows system drive.</p> <p>A web browser and Adobe Acrobat Reader to be able to access all the product documentation.</p>
<b>Host interface</b>	USB interface that enables communication based on USB (Ver1.1 or later)

**Note:** Updates of the IAR Embedded Workbench for 78K, documentation and/or utilities for **78K0-SAVEIT**, if available, may be downloaded from the NEC WEB page(s) at <http://www.eu.necel.com/78K0-SAVEIT>

### 1.4 Trademarks

IAR Embedded Workbench, visualSTATE and C-SPY are registered trademarks of IAR Systems AB. Microsoft and Windows are registered trademarks of Microsoft Corporation. Adobe and Acrobat Reader are registered trademarks of Adobe Systems Incorporated.

All other product names are trademarks or registered trademarks of their respective owners.

## 2. 78K0/Kx2-L – Save It! Components

The TK-78K0/KC2L board is equipped with USB-connector and with several connectors in order to be connected to host computers, FLASH programmer, MiniCube2 or any external target hardware.




Figure 1: 78K0/Kx2-L – Save It! components

### 2.1 Operation mode settings

To support the different operation modes of the 78K0/Kx2-L – Save It! switches and jumpers are available on the TK-78K0/KC2L board.

The table below shows the 3 different modes and the regarding switch / jumper setting for each mode.

Switch / Jumper	Demonstration mode	Debugging / Writing mode	PC communication mode
SW1	DEMO	Debug	K0USB
SW2	DEMO	EXT	K0USB
SW3.1 – SW3.3	OFF	ON	OFF
SW3.4 – SW3.8	Unused	Any	Any
JP1	Short	Short	Short
JP2	1-2 and 3-4 shorted	1-3 shorted	1-3 shorted

Table 1: 78K0/Kx2-L – Save It! Switch and Jumper settings

#### Demonstration mode:

This mode has to be selected if an application is already programmed in the device and shall run standalone. Use this to run the pre-programmed low power consumption demonstration.

**Debug / Writing mode:** Use this mode if you want to establish a debug session using the IAR C-SPY debugger or if you want to write an application to the 78F0588 microcontroller using the WriteEZ5 flash programmer software.

**PC communication mode:** Set this mode if you want to establish a UART communication between the Host PC and the 78K0/KC2-L microcontroller mounted to the demonstration kit. The Host PC has to be connected via USB1 to the 78K0/Kx2-L *Save it!* demonstration kit. After connecting the board shows up as an additional COM port on the Host PC.

## 2.2 SW1

SW1 is a 3 position switch to set following modes.

Position	Mode
Left	Demo
Middle	K0USB
Right	Debug

Table 2: SW1 modes

## 2.3 SW2

SW2 is a 3 position switch to set following modes.

Position	Mode
Left	Demo
Middle	K0USB
Right	EXT

Table 3: SW2 modes

## 2.4 SW3

SW3 is an 8 position DIP switch with following functions

Bit	Mode
1	Mode selection (see Table 1)
2	Mode selection (see Table 1)
3	Mode selection (see Table 1)
4	Connected to microcontroller port pin P70
5	Connected to microcontroller port pin P71
6	Connected to microcontroller port pin P72
7	Connected to microcontroller port pin P73
8	Connected to microcontroller port pin P74

Table 4: SW3 modes

**Note:** Make sure to set the regarding pull-up resistor option registers (PU7) of the microcontroller if the Pins P70, P71, P72, P73 and P74 are used. Please refer to the [device user's manual](#) of the 78K0/Kx2-L for detailed information about the pull-up resistor option register settings.

## 2.5 SW4 (Reset switch)

SW4 is connected to the external reset pin of the  $\mu$ PD78F0588 microcontroller. External microcontroller reset can be triggered by pushing.

## 2.6 SW5 (INTP1)

SW5 is connected to the "P30/INTP1" pin of the  $\mu$ PD78F0588 microcontroller. It can be used as external interrupt source.

**Note:** Make sure to set up the microcontroller internal pull-up resistor option register (PU12) correctly when using this external switch. Please refer to the [device user's manual](#) of the 78K0/Kx2-L for detailed information about the pull-up resistor option registers settings.

### 2.7 SW6 (INTP4)

SW6 is connected to the "P33/TO51/TI51/INTP4" pin of the  $\mu$ PD78F0588 microcontroller. It can be used as external interrupt source.

**Note:** Make sure to set up the microcontroller internal pull-up resistor option register (PU12) correctly when using this external switch. Please refer to the [device user's manual](#) of the 78K0/Kx2-L for detailed information about the pull-up resistor option registers settings.

### 2.8 JP1

JP1 is a switch jumper to select the power supply.

Position	Function
Short	USB power supply connected (USB1)
Open	Power supply via CN1 or CN2

Table 5: JP1 settings

### 2.9 JP2

JP2 is a jumper field to establish a current consumption measurement

Jumper settings	setting
1-2 and 3-4 short	Demonstration mode
1-3 short	Debugging/Writing and PC communication mode
any other	restricted

Table 6: JP2 settings

### 2.10 Q4 (illuminance sensor)

The illuminance sensor Q4 is connected to the "P10/SCK10/ANI8/AMP1-" pin of the  $\mu$ PD78F0588 microcontroller. When lightening up the voltage increases and when making dark it decreases. So the gain amplifier function of the microcontroller can be used to read the illuminance. For further information to set up the registers of the microcontroller to use the gain amplifier functionality please refer to the [device user's manual](#).

### 2.11 U8, U10 (7-segment LED)

U8 and U10 are two 7-segment LEDs. They can be set through the latches U9 and U11. The data channels of the latch are connected to channel P20 to P27 and the clock pins to P00 (U8) and P01 (U10) of the of the  $\mu$ PD78F0588 microcontroller.




Figure 2: 78K0/Kx2-L – Save It! 7-segment LEDs structure




Figure 3: 78K0/Kx2-L – Save It! 7-segment LED port pin connection

In respect to the pin connection the following table shows the port values to be written to show the numbers from 0 to 9 on the 7-segment LEDs.

Digital number	Port value (hex)	Digital number	Port value (hex)
0	0xC0	5	0x92
1	0xF9	6	0x83
2	0xA4	7	0xF8
3	0xB0	8	0x80
4	0x99	9	0x98

Table 7: 7 segment LED port values

**2.12 LED1 (power LED)**

LED1 is the power LED, lights up when power is supplied via USB, CN3 (not mounted) or J1 (not mounted) to the 78K0/Kx2-L – Save It!

**2.13 Universal area**

The Universal area of the 78K0/Kx2-L – Save It! is a free for the customer to use mounting area. It can be found in the lower right corner of the TK-78K0/KC2L board.

**2.14 Minicube2 connector**

If a MiniCube2 shall be connected to the 78K0/Kx2-L – Save It! starter kit a 16-pin connector has to be mounted to the FP1 area shown below.




Figure 4: 78K0/Kx2-L – Save It! MiniCube2 connector



3. 78K0/Kx2-L – Save it! Solder-short pads

On the TK-78K0/KC2L board you will find several solder-short pads. By opening or connecting these pads the circuit design of the TK-78K0/KC2L board can be customized.




Figure 5: 78K0/Kx2-L starter kit Solder-short pads

The solder-short pad looks like the picture below. To open, use a cutter to cut the dent part. To short, put solder on the pad.

Solder-short pad (Open)



Solder-short pad (Short)



Solder-short pad name	Before Shipment	Connection	
P20~P27	Short	Short Open	7seg LED via 74AC574. You can use port2 for multipurpose I/O.
P00~P01	Short	Short Open	7seg LED via 74AC574. You can use port00,01 for multipurpose I/O.
P10	Short	Short Open	Port10 is connected to Illuminance Sensor. You can use port10 for multipurpose I/O.
P30	Short	Short Open	Port30 is connected to SW5. You can use port30 for multipurpose I/O.
P33	Short	Short Open	Port33 is connected to SW6. You can use port33 for multipurpose I/O.
AVREF	Open	Short Open	AVREF is connected to AVREF. AVREF is separated from AVREF.
AVREF0	Short	Short Open	VDD0 is connected to AVREF. VDD0 is separated from AVREF.
AVREF1	Short	Short Open	VDD is connected to AVREF. VDD is separated from AVREF.
DCVDD1,DCVDD2	Open	Short Open	CN3, J1 is connected to VDD. CN3, J1 is separated from VDD.
LEDVDD1,LEDVDD2	Short	Short Open	7segLED is connected to VDD. 7segLED is separated from VDD.

Table 8: 78K0/Kx2-L – Save it! Solder short pads



#### 4. 78K0/Kx2-L – Save It! system configuration

The 78K0/Kx2-L – Save It! starter kit system configuration is given in the diagram below




Figure 6: 78K0/Kx2-L- Save It! system configuration

##### 4.1 78K0/Kx2-L – Save It!

The 78K0/Kx2-L – Save It! is a demonstration kit for the 78F0588 8-bit low power consumption microcontroller of the NEC 78K0 family. The demonstration board is connected to the host system via an USB interface cable. The host system may be used for On-Chip debugging by using the IAR C-SPY debugger and to allow execution of application programs on 78K0/Kx2-L – Save It! starter kit.

78K0/Kx2-L – Save It! runs the microcontroller at 10 MHz operating speed in normal operation mode.

##### 4.2 Host computer

The USB host interface enables communication to the 78K0/Kx2-L – Save It! board. The  $\mu$ PD78F0730 NEC 78K0 8-Bit microcontroller with on-chip USB interface and the NEC virtual UART driver allows application software to access the  $\mu$ PD78F0588 device in the same way as it would access a standard RS232 interface. The NEC virtual UART driver appears to the windows system as an extra Com Port, in addition to any existing hardware Com Ports.

##### 4.3 Power supply

The TK-78K0/KC2L board can be powered by the USB interface. Optional the power supply can be applied via a JACK connector, which has to be mounted to CN3, or a connector plug mounted to J1.

**Note:** When connecting a power supply to CN3 or J1 make sure to open (disconnect) JP1!

## 5. 78K0/Kx2-L – Save It! installation and operation

### 5.1 Getting started

The *78K0/Kx2-L – Save It!* is delivered with two PC based user programs. The TK-78K0KC2L demonstration program is designed to measure the current consumption, the CPU frequency and the actual illuminance (measured by an illuminance sensor on the TK-78K0/KC2L board). The Applilet3 for 78K0/Kx2-L is an easy to use GUI based program to configure available device peripherals driver which are automatically converted into an IAR Embedded workbench or NEC PM+ project.

### 5.2 CD-ROM contents










NEC 78K0/Kx2-L - Save It!	CD-ROM ROOT
 Acrobat	- Acrobat Reader for 32 Bit Windows OS
 Applilet	- Applilet3 for 78K0/Kx2-L
 Doc	- Documentation
 dotnet	- Microsoft .NET package
 Driver	- TK-78K0/KC2L USB driver files
 IAR Systems	- IAR Embedded Workbench for 78K - IAR visualSTATE
 sample projects	- Example projects for the <i>78K0/Kx2-L - Save It!</i> Starter Kit
 TK-78K0_KC2L_Demo	- TK-78K0RKE3L current consumption demonstration program
 WriteEZ5	- Flash Programmer WriteEZ5 incl. PRM file for $\mu$ PD78F0588

Figure 7: 78K0/Kx2-L – Save It! CD-ROM contents

## **6. Hardware installation**

After unpacking the *78K0/Kx2-L – Save It!* demonstration kit, connect the board via connector USB1 to your host computer using the provided USB interface cable. When TK-78K0/KC2L board is connected, the USB driver needs to be installed on the host machine. Please refer to the following [USB Driver Installation](#).

## 7. Software installation

The 78K0/Kx2-L – Save It! package comes with the following software packages:

- TK-78K0/KC2L demonstration program
- IAR Systems Embedded Workbench for 78K 4Kbyte code size limited, including C compiler, assembler, linker, librarian and IAR C-SPY debugger / simulator
- IAR Systems visualSTATE 20 states limited demo program
- Applilet3 for 78K0/Kx2-L
- WriteEZ5 flash programmer software including PRM file for  $\mu$ PD78F0588
- Adobe Acrobat Reader 9.3



Figure 8: 78K0/Kx2-L – Save It! CD-ROM autorun.exe

### 7.1 TK-78K0KC2L demonstration program installation

Before the TK-78K0KC2L demonstration program can be installed on the host PC it is mandatory that the .NET Framework is installed on the host PC. For further information about installing .NET Framework please refer to the TK-78K0\_DEMO\_GUI\_e.pdf available on the CD delivered with the 78K0/Kx2-L – Save It! package in the “\Doc” folder.

To install the TK-78K0/KC2L demonstration program press the Software tools button from the Autorun of the CD-ROM provided within the 78K0/Kx2-L – Save It! package and select the regarding entry from list. The

setup dialogues will guide you through the installation process. The installation can also be started by executing the "TK-78K0\_KC2L Demo.msi" in the directory "\\TK-78K0\_KC2L Demo" of the CDROM.

## 7.2 IAR Systems Embedded Workbench for 78K installation

To install the IAR Systems Embedded Workbench for 78K including C-SPY debugger / simulator press the Software tools button from the Autorun of the CD-ROM provided within the *78K0/Kx2-L – Save It!* package and select the regarding entry from list. The installation can also be started by executing the `Autorun.exe` program in the directory "\\IAR Systems\\" of the CDROM.

When running the `autorun.exe` the following screen appears.




Figure 9: IAR Systems Installation screen

**Note:** Before installing the IAR Embedded Workbench for 78K 4KB code size limited version a license number and key has to be requested from IAR Systems. Therefore please follow the IAR online registration. The license number and key shall be provided within a view minutes after the request is submitted.

To install the IAR Embedded Workbench for 78K just press the regarding button "Install IAR Embedded Workbench®". The setup dialogues will guide you through the installation process.

### 7.3 IAR Systems visualSTATE Installation

To install the IAR Systems visualSTATE press the Software tools button from the Autorun of the CDROM provided within the *78K0/Kx2-L – Save It!* package. The installation can also be started by executing the `Autorun.exe` program in the directory “\IAR Systems\” of the CDROM. [The IAR Systems Installation screen](#) will appear and the installation of IAR visualSTATE can be started by pressing the “Install visualSTATE<sup>®</sup>” button. The setup dialogues will guide you through the installation process.

### 7.4 Applilet3 for 78K0/Kx2-L

To install the Applilet3 for 78K0/Kx2-L press the Software tools button from the Autorun of the CD-ROM provided within the *78K0/Kx2-L – Save It!* package and select the regarding entry from list. The setup dialogues will guide you through the installation process. The installation can also be started by executing the `setup.exe` in the directory “\Applilet\AP3-78K0KX2L-EE\_V110” of the CDROM.

### 7.5 WriteEZ5 installation

To install the WriteEZ5 press the Software tools button from the Autorun of the CD-ROM provided within the *78K0/Kx2-L – Save It!* package and select the regarding entry from list. The setup dialogues will guide you through the installation process. The installation can also be started by executing the `WriteEZ5_V100_EE.exe` in the directory “\WRITEEZ5” of the CDROM.

### 7.6 Sample projects

To copy the sample programs to your Host PC press the regarding button “Sample projects”. The setup dialogues will guide you through the copying process. The installation can also be started by executing the “78K0-SAVEIT\_sample\_projects\_V100.exe” in the directory “\sample projects” of the CDROM.

### 7.7 USB Driver Installation

In order to use the TK-78K0/KC2L board, the USB driver needs to be installed on the host machine. Install the driver according to the following procedure:

Installation on Windows 2000	Page 22
Installation on Windows XP	Page 26

#### 7.7.1 Installation on Windows 2000

1. When the TK-78K0/KC2L is connected with the host machine, the board is recognized by <Plug and Play>, and the wizard for finding new hardware is started. Click **Next**.



Figure 10: Found New Hardware Wizard (Windows 2000)

2. Following the window below is displayed. So, check that "Search for a suitable driver ..." is selected, then click **Next>**.




Figure 11: Search Method (Windows 2000)

3. Check the "Specify a location" check box only, then click **Next>**.




Figure 12: Driver File Location (Windows 2000)

4. Locate to the folder "CDROM:\Driver".




Figure 13: Address Specification 1 (Windows 2000)

5. The setup information file "MQB2ALL.inf" is automatic selected, then click **Open** to proceed within driver installation.






Figure 14: Address Specification 2 (Windows 2000)

6. After the location of the USB driver has been specified click **OK** to proceed.




Figure 15: Address Specification 3 (Windows 2000)

7. Click **Next>**.




Figure 16: Driver File Search (Windows 2000)

- Click **Finish** to complete the installation of the USB driver.



Figure 17: USB Driver Installation Completion (Windows 2000)

### 7.7.2 Installation on Windows XP

- When the TK-78K0/KC2L board is connected with the host machine, the board is recognized by Plug and Play, and the wizard for finding new hardware is started. At first the hardware wizard will ask if windows should search on the windows update web, check "No, not this time" and then click **Next>**.



Figure 18: Found New Hardware Wizard 1 (Windows XP)

- Check that "Install from a list or specific location (Advanced)" is selected, then click **Next>**.




Figure 19: Found New Hardware Wizard 2 (Windows XP)

3. Check that "Search for the best driver in these locations." is selected. Select the "Include this location in the search:" check box and then click **Browse**.




Figure 20: Search Location Specification 1 (Windows XP)

4. Locate the folder "C **CDROM**:\Driver" and click **OK**.




Figure 21: Search Location Specification 2 (Windows XP)

- 5. As shown below, "NEC Electronics Starter Kit Virtual UART has not passed Windows Logo testing to verify its compatibility with Windows XP." is displayed. Click Continue Anyway.




Figure 22: Windows XP Logo Testing (Windows XP)

- 6. After the installation of the USB driver is completed the window below is displayed. Click Finish to close the hardware wizard.




Figure 23: USB Driver Installation Completion (Windows XP)

### 7.8 Confirmation of USB Driver Installation

After installing the USB driver, check that the driver has been installed normally, according to the procedure below. When using the Save It! board the “NEC Electronics Starter Kit Virtual UART” should be present like in the figure below.

Please check in the Windows "Device Manager" within the Windows Properties (“Hardware” tab), that the driver is installed normally.




Figure 24: Windows Device Manager

## 8. Flash Programmer WriteEZ5

WriteEZ5 is flash programming software to flash hex files to the related device. For installation information refer to the chapter [WriteEZ5 installation](#).




Figure 25: WriteEZ5 Startup

### 8.1 Device Setup

To provide all necessary information about the device to be programmed, only the corresponding flash parameter file must be loaded. The parameter file (\*.prm) for the  $\mu$ PD78F0588 is located on the CDROM in the WriteEZ5 folder. Please use the menu “**Device -> Setup...**” to open the following dialogue and the button “**PRM File Read**” to select the parameter file.




Figure 26: WriteEZ5 Device Setup Dialogue

Please check that the correct host communication port is selected. The used communication port can be seen in the [Windows Device Manager](#).

8.2 Using WriteEZ5

After a successful device selection the internal flash memory can be blank-checked, erased, programmed or verified. WriteEZ5 can be controlled either by menu or by buttons




Figure 27: WriteEZ5 Device Menu







	device setup button
	load file button
	blank check button
	erase button
	program button
	verity button
	Autoprocedure button

Table 9: WriteEZ5 action buttons

WriteEZ5 supports Intel-Hex and Motorola S-record file formats as input file.

## 9. Demo application using the TK-78K0/KC2L demonstration program

The Low-Power-Consumption Demonstration GUI for the *78K0/Kx2-L – Save It!* is a Windows software that can be used to check the operation of the 8-bit microcontroller 78K0/KC2-L mounted on the included demonstration kit board TK-78K0/KC2L made by TESSERA Technology Inc. by performing a simplified display of the features and power of the microcontroller.

The Demo GUI allows the user to monitor the on-chip oscillator of the KC2-L, the power consumption, and the optical sensor mounted on the TK Board, and to easily switch among the full-speed mode to standby mode. The current in a user program can also be measured.




Figure 28: TK-78K0/KC2L demonstration program

**Note:** Values displayed on the GUI

Reference values are displayed on the GUI. Results that do not satisfy the device specifications might be displayed depending on the resistor for detecting current and the resonator or measuring the frequency used on the board. Use the values only as a reference for design and evaluation. Use calibrated measuring equipment if precise measurement is required.



For further information about usage and functionality of the tool please refer to the TK-78K0/KC2L demonstration program User's manual (TK-78K0\_DEMO\_GUI\_e.pdf). The manual can be found on the 78K0/Kx2-L – Save It! CDROM in the “\Doc” folder.

## 10. Applilet3 for 78K0/Kx2-L

### 10.1 Overview

Applilet3 for 78K0/Kx2-L is an easy to use device driver Configurator for all 78K0/Kx2-L devices. All available internal device peripherals can be configured by this GUI based software tool. For further descriptions about the Applilet3 refer to the regarding User's Manual (U19178EJ4V0UM00.pdf) available on the *78K0/Kx2-L – Save It!* CD-ROM in the “\Doc” folder.




Figure 29: Applilet3 for 78K0/Kx2-L main window

### 10.2 Applilet3 for 78K0/Kx2-L sample application

After copying the [sample project](#) to the Host PC you will find the Applilet3 for 78K0/Kx2-L project file (78K0-SAVEIT\_sample\_project.cgp) in the subfolder AP3+EWB of the location where you have copied the sample projects to. To open this project start the Applilet3 for 78K0/Kx2-L and use the File → Open function. After loading the project you will see the [Applilet3 for 78K0/Kx2-L main window](#). The peripheral driver configuration created with the Applilet3 for 78K0/Kx2-L is also be used for the [IAR Embedded Workbench 78K0/Kx2-L – Save It! sample project](#).

### 10.2.1 Clock and On-chip debug settings

The system clock for this project is set up to use the high-speed system clock. This makes use of the oscillator Y1 (10MHz) which is mounted to the target hardware. Furthermore the Subsystem clock is enabled to generate a frequency of 32.768 KHz that is needed for the RTC. As this Applilet3 for 78K0/Kx2-L sample project shall be used as basic driver initialization for the IAR Embedded Workbench sample the On-chip debug function has to be enabled to configure the option bytes correctly.




Figure 30: Applilet3 for 78K0/Kx2-L On-chip debug window

### 10.2.2 Timer setting

The [Count mode](#) of the IAR Embedded Workbench sample project uses an interval timer interrupt to count up. Therefore the timer TM00 has to be configured in the Applilet3 for 78K0/Kx2-L as shown below with an Interval value of 3.3024ms.




Figure 31: Applilet3 for 78K0/Kx2-L Timer Function select




Figure 32: Appilet3 for 78K0/Kx2-L Timer TM0 settings

### 10.2.3 RTC setting

The Real-time counter has also to be configured as the [Blink](#) and the [Spinning](#) mode make use of it in the sample project. The blink modes uses the INTERTC interrupt with an interrupt time of 0.5 seconds.




Figure 33: Appilet3 for 78K0/Kx2-L RTC settings

The spinning mode uses the INTRTCI interrupt with and period value of 31.25ms.




Figure 34: Applilet3 for 78K0/Kx2-L RTCI settings

### 10.2.4 Interrupt setting

To switch between the modes of the sample project the mounted switches SW6 and SW6 of the TK-78K0/KC2L board are used. These switches are connected to the external interrupt pins INTP1 and INTP4.




Figure 35: Applilet3 for 78K0/Kx2-L External Interrupt settings

**10.2.5 Port setting**

Port2 and the Port0 pins 0 and 1 are used to control the two 7-segment LEDs of the TK-78K0/KC2L and therefore have to be configured as input pins. The pins 0-4 of Port 7 are used as input pins connected to SW3 (4-8). And select which segments of the two 7-segment LEDs are blinking in the Blink mode.

## 11. IAR Embedded Workbench 78K0/Kx2-L – Save It! sample project

The IAR Embedded Workbench IDE is a very powerful Integrated Development Environment that allows you to develop and manage a complete embedded application project.

The described sample project `78K0-SAVEIT_sample_project.eww` is a part of the [Sample programs](#) and can be found on after installation in the regarding subfolder “\AP3+EWB\applilet3\_src” of the installation.

To run/debug the project with the IAR C-SPY debugger it is necessary to follow the steps described below in this chapter.

For further information about the IAR Embedded Workbench and the included functionalities please refer to the regarding User’s manuals available on the – *Save It!* CR-ROM in the “\IAR Systems\doc” folder.

### 11.1 Hardware setup

To run the program it is necessary to set up the TK-78K0/KC2L board in the following way.

Switch / Jumper	Mode position
SW1	Debug
SW2	EXT
SW3.1 – SW3.3	ON
SW3.4 – SW3.8	Any
JP1	Short
JP2	1-3 shorted

Table 10: IAR EWB 78K0/Kx2-L – Save It! sample project hardware setup

### 11.2 Loading the 78K0/Kx2-L Save It! sample project

After starting the IAR Embedded Workbench for 78K the Startup window pops up. In this window you are able to choose the **Open existing workspace** button.




Figure 36: IAR Embedded Workbench Startup window

Then locate the sample project on the CD and open the `SAMPLE-TK-78K0KC2L.eww` workspace file. Afterwards the IDE should look similar like below.




Figure 37: IAR Embedded Workbench Main IDE window

To verify that the right debugging device is chosen please open the project options window by clicking **Project** → **Options** and then open the tab **Debugger**.

**Note:** Although the On-board debug interface is used, the MINICUBE C-Spy driver must be selected instead of the standard driver TK-78K used for other starter kits. If the debug session via MINICUBE2 and the OCD1 connectors shall be started, also the MINICUBE C-Spy driver must be selected.

The corresponding COM port where the *TK-78K0/KC2L board* is connected to the host PC will be detected automatically by the IAR C-SPY debugger.






Figure 38: IAR Embedded Workbench Debugger Options

The next step is to check that the correct linker settings are set. This can be done in the “Linker” category as shown below. Select the “Config” tab and check that the linker command file “lnk78f0588.xcl” is selected. This file is used by the linker and contains information on where to place the different sections of code, data and constants that may be used within the demo project:





Figure 39: Embedded Workbench Linker Configuration

Now after everything has been setup correctly it's time to compile and link the demonstration project. Close the Options menu and select "Rebuild All" from the "Project" menu. If the project is compiled and linked without errors or warnings it can now be downloaded to the *78K0/Kx2-L Save It!* board and debugged.

To start the IAR C-SPY debugger select the option "Debug" from the "Project" menu or press the (  ) "Debugger" button.

When first starting the debugger connection, after building the project, it is necessary to set up the right connection settings. Please take care that the following settings are chosen:

- ID code = FFFFFFFFFFFFFFFFFF
- Main clock = System 8.00 MHz
- Target connect = TOOLC/D




Figure 40: IAR Embedded Workbench MINICUBE2 settings

Now the debugger is started and the demo project is downloaded to the *78K0/Kx2-L Save It!* board. The progress of downloading is indicated by blue dots in the MINICUBE Emulator window. Please note that downloading of larger executables may take some time.

After the download was completed all debug features of IAR C-SPY debugger are available, i.e. Single Stepping, Step Over/-In/-Out, Go-Execution, Breakpoints, Register / Memory view etc.

To get more details on the debugger configuration and capabilities please refer to the "78K IAR Embedded Workbench IDE User Guide" of the IAR installation.




Figure 41: IAR C-SPY debugger

### 11.3 Running the application

After downloading the project to the device the debugger window opens and, if not changed by the user, the program runs to the first instruction of the main() function. When reaching this point the necessary clock initialization is already executed.

This sample project makes use of different timer interrupts to control the 7-segment LEDs available on the TK-78K0/KC2L board. So this project gives a short overview about timer initialization and timer interrupts usage of one timer as well as the real time clock (RTC) peripheral.

#### 11.3.1 Count mode

When resuming execution of the program, after the break when entering the main function, the controller starts to count up from 0 to 39 on the 7-segment LEDs. This is controlled by the timer TM00 which is initialized as an interval timer. Furthermore every time the interrupt occurs and the value is counted up the interval time increases. During this stage both external interrupts INTP1 and INTP4 are disabled.

#### 11.3.2 Blink mode

After the counter reached its final value of 39 the used timer interrupt is masked and the RTC interrupt will be unmasked and is used for the next stage. Furthermore INTP1 is unmasked to be able to leave this stage whenever the user wants to.

The only function of this stage is to let the final counter value blink in a frequency of 2Hz controlled by the RTC interrupt. To leave this stage SW5 has to be pressed once.

### 11.3.3 Spinning mode

When entering the Spinning mode the RTC interrupt and the INTP1 will be masked again. In exchange the RTCI Interrupt, which occurs every 31.25ms and the INTP4 are unmasked. The function of the Spinning mode is to spin 1 active segment around the 2 x 7-segment LEDs. So every time a RTCI interrupt occurs the active segment is stepped clockwise to the next segment on the outer ring of both 7-segment LEDs. To leave this mode the SW6 has to be pressed to trigger an external interrupt. When leaving the spinning mode the [Count mode](#) is entered again.

## 12. IAR visualSTATE 78K0/Kx2-L – Save It! sample project

IAR visualSTATE is a Windows-based software package of integrated tools for developing, testing, and implementing embedded applications based on state-chart diagrams. It includes a graphical design environment, test tools, a code generator, and a documentation facility.

IAR visualSTATE has been developed in accordance with the Unified Modeling Language notation (UML).

For more information please refer to the `UserGuide.pdf` included to the 78K0/Kx2-L –Save It! CD-ROM in the “\doc\visualSTATE” folder or to the [visualSTATE homepage](#)

**Note:** Before installing IAR visualSTATE please make sure that you have installed the IAR Embedded Workbench for 78K delivered with the 78K0/Kx2-L Save It! demonstration kit.

**Note:** After installing IAR visualSTATE copy the the `swtdvs.dll` to the <EW>\78k\bin directory and the `vs.ewplugin` file to <EW>\common\plugins directory. These files are located in the “IAR Systems\Plugin” folder of the demonstration kit CD-ROM.

The described sample project `React.vnw` is a part of the [Sample programs](#) and can be found on after installation in the regarding subfolder “\visualSTATE\vs” of the installation.

### 12.1 Hardware setup

To run the program it is necessary to set up the TK-78K0/KC2L board in the following way.

Switch / Jumper	Mode position
SW1	Debug
SW2	EXT
SW3.1 – SW3.3	ON
SW3.4 – SW3.8	Any
JP1	Short
JP2	1-3 shorted

Table 11: IAR VS 78K0/Kx2-L – Save It! Sample project hardware setup

### 12.2 Functionality of the sample project

The example implements a reaction timing measurement application that measures your reaction time a fixed number of times and then displays the average reaction time in hundredths of a second. The application works in the following way:

- When the application is started it displays two '-' characters on the display and waits for a press on any of the two buttons.
- A timer with a fairly random interval is now started and when the timer times out a '[' or ']' symbol is displayed on the left or right digit respectively. A new timer is also started for the measurement of your reaction time.
- You should now as fast as possible press the left button (SW5) if the '[' is shown or the right button (SW6) if the ']' is shown. The time for you to react is read from the timer and added to a running sum.
- After a button press the process is repeated until 10 trials has been performed. Your average reaction time is now displayed and you can press a button to get back to the initial state and restart the measurement if you want to.

The state machine is implemented with 3 input events (button presses and an expired timer) and 10 small C functions for the interface to the hardware. There are 5 states to keep track of what is currently going on in

the application. This is not the only plausible state machine implementation for this application. An alternative could for example be to have separate, parallel and communicating state machines for time measurement and display updates.

Further details on the sample project can be found in the `index.html` file available in the *78K0/Kx2-L – Save It!* CD-ROM “\doc\visualSTATE\samples” folder.

### 12.3 Running the sample project

To perform changes on the visualSTATE parts open the visualSTATE workspace file within the “\samples\IAR visualSTATE sample project\vs” folder of the CD-ROM. After loading the workspace the window should look like shown below.




Figure 42: IAR visualSTATE navigator

If the functionality or the settings of the sample shall be changed open the visualSTATE Designer.




Figure 43: IAR visualSTATE designer

To run the project on the TK-78K0/KC2L board locate the IAR Embedded Workbench workspace file (78K0-SAVEIT\_sample\_project.eww) within the "\visualSTATE\EW" folder of the installation of the sample projects.




Figure 44: IAR Embedded Workbench visualSTATE sample project

When loading the visualSTATE sample project all necessary settings to run the application on the TK-78K0/KC2L are already set. So the user just has to download the application to the target device.

The application can be downloaded by click Project → Debug.

**Note:** When facing the following error messages during the build process of the IAR project please use the Rebuild all function within the IAR Embedded Workbench (Project → Rebuild all).

**Error[e46]:** Undefined external "ReactionSEM\_InitAll" referred in main ("Project Dir"\Debug\Obj\main.r26 )  
**Error[e46]:** Undefined external "ReactionVSAction" referred in main ("Project Dir"\Debug\Obj\main.r26 )  
**Error[e46]:** Undefined external "ReactionSEM\_GetOutput" referred in main ("Project Dir"\Debug\Obj\main.r26 )  
**Error[e46]:** Undefined external "ReactionSEM\_NextState" referred in main ("Project Dir"\Debug\Obj\main.r26 )  
**Error[e46]:** Undefined external "ReactionSEM\_Deduct" referred in main ("Project Dir"\Debug\Obj\main.r26 )

For further information regarding this issue please refer to the IAR visualSTATE Release Notes (readme.en.html) available in the root directory of the IAR visualSTATE installation

#### 12.4 Debug the 78K0/Kx2-L – Save It! visualSTATE sample project

After downloading the application to the target device all from the C-SPY debugger already known debug features are available. Furthermore more visualSTATE specific Debug features can be used like an actual State view or a graphical animation of the states and state switches. For further information about the visualSTATE C-SPY plug-in please refer to the regarding chapter in the C-SPYLinkUserGuide.pdf which is located in the "\\doc\visualSTATE" folder.



13. Cables

13.1 USB interface cable (Mini-B type)




Figure 45: USB interface cable (Mini-B type)

**14. Schematics**

Please find the schematics attached to this document. To open the attachments view in the Adobe Reader press the paper clip in the lower left corner of the window. To open the attachment double click the TK-78K0KC2L\_schematic.pdf

[MEMO]