

## **User's Manual**

### **ECM-5716 Series**

**All-in-One Pentium-M Single Board  
with LVDS, TMDS, AC97 Audio, IEEE-1394A, PCMCIA,  
Dual 10/100Base-Tx Ethernet Interfaces, 4USB 2.0, 2COMs & Intel  
Gigabit Ethernet Interface (optional)**

3<sup>rd</sup> Ed. – 16 November 2004

**ECM-5716 Series**

**FCC STATEMENT**

THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.

(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE

RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE  
OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

## Copyright Notice

Copyright © 2004 Evalve Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

## Trademark Acknowledgement

Brand and product names are trademarks or registered trademarks of their respective owners.

## Disclaimer

Evalve Technology Inc. reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. Evalve Technology assumes no responsibility or liability for the use of the described product(s) and conveys no license or title under any patent, copyright or mask work rights to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. Evalve Technology Inc. makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

## Life Support Policy

Evalve Technology's PRODUCTS ARE NOT FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE PRIOR WRITTEN APPROVAL OF Evalve Technology Inc.

As used herein:

1. Life support devices or systems are devices or systems which, (a) are intended for surgical implant into body, or (b) support or sustain life and whose failure to perform, when properly used in accordance with instructions for use provided in the labelling, can be reasonably expected to result in significant injury to the user.
2. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

## ECM-5716 Series

### **A Message to the Customer**

#### **Evalue Customer Services**

Each and every Evalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Evalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Evalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Evalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

## Technical Support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult this manual first.

To receive the latest version of the user manual, please visit our Web site at:

<http://www.evaluate-tech.com/>

If you still cannot find the answer, gather all the information or questions that apply to your problem, and with the product close at hand, call your dealer. Our dealers are well trained and ready to give you the support you need to get the most from your Evaluate's products. In fact, most problems reported are minor and are able to be easily solved over the phone.

In addition, free technical support is available from Evaluate's engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products. Please do not hesitate to call or e-mail us.

### Headquarters

#### **Evaluate Technology Inc.**

7F, 228, Lian-Cheng Road,  
Chung-ho City, Taipei,  
Taiwan

Tel: +886-2-82262345

Fax: +886-2-82262777

<http://www.evaluate-tech.com>

E-mail: [service@evaluate-tech.com](mailto:service@evaluate-tech.com)

### Europe Branch Office

#### **Evaluate Europe A/S**

Nordre Strandvej 119C,  
3150 Hellebaek,  
Denmark

Tel : +45-7025-0310

Fax : +45-4975-5026

<http://www.evaluate-tech.com>

E-mail: [service.europe@evaluate-tech.com](mailto:service.europe@evaluate-tech.com)

### China Branch Office

#### **Evaluate Technology Shanghai Inc.**

Room 909, 9F, Section B, No.900,  
Yisan Road, Caohejing Hi-tech Park,  
Shanghai 200233, China

Tel : +86-21-6470-3454

Fax : +86-21-6470-3454

<http://www.evaluate-tech.com>

E-mail: [service.china@evaluate-tech.com](mailto:service.china@evaluate-tech.com)

### US Branch Office

#### **Evaluate Technology Inc.**

Suite 210, 200 Tornillo Way,  
Tinton Falls, NJ 07712  
USA

Tel: +1-732-578-0200

Fax: +1-732-578-0250

<http://www.evaluate-tech.com>

E-mail: [service.usa@evaluate-tech.com](mailto:service.usa@evaluate-tech.com)

## ECM-5716 Series

### Product Warranty

Evalue warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Evalue, or which have been subject to misuse, abuse, accident or improper installation. Evalue assumes no liability under the terms of this warranty as a consequence of such events. Because of Evalue's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Evalue's product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time, and freight. Please consult your dealer for more details. If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU type and speed, Evalue's products model name, hardware & BIOS revision number, other hardware and software used, etc.) Note anything abnormal and list any on-screen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return material authorization) number from your dealer. This allows us to process your good return more quickly.
4. Carefully pack the defective product, a complete Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

## Packing List

Before you begin installing your single board, please make sure that the following materials have been shipped:

- 1 ECM-5716 series All-in-One Pentium-M Computing Module
- 1 Quick Installation Guide
- 1 CD-ROM contains the followings:
  - User's Manual (this manual in PDF file)
  - Ethernet driver and utilities
  - VGA drivers and utilities
  - Audio drivers and utilities
- Cable set includes the followings:
  - 1 ATA100 IDE cable (40-pin, pitch 2.54mm)
  - 1 FDD cable (34-pin, pitch 2.54mm)
  - 1 Daughter board supports Audio / 2USB (P/N: 9697000105)
  - 1 Flat cable for audio (16-pin, pitch 2.0mm/16-pin, 2.54mm)
  - 1 Flat cable for USB 2.0 (10-pin, pitch 2.54mm)
  - 1 Bracket with 1 serial & 1 printer cable (10-pin 2.54mm/26-pin 2.54mm)
  - 1 PS/2 KB/Mouse Y cable

If any of these items are missing or damaged, please contact your distributor or sales representative immediately.

## ECM-5716 Series

<b>1. MANUAL OBJECTIVES .....</b>	<b>1</b>
<b>2. INTRODUCTION.....</b>	<b>2</b>
<b>2.1 System Overview.....</b>	<b>2</b>
<b>2.2 System Specifications .....</b>	<b>3</b>
<b>2.3 Architecture Overview .....</b>	<b>6</b>
2.3.1 855GME and 82801DB.....	7
2.3.2 DRAM Interface.....	9
2.3.3 Chrontel CH7301 DVI Transmitter.....	9
2.3.4 PCI Interface .....	9
2.3.5 IDE Interface (Bus Master Capability and Synchronous DMA Mode).....	9
2.3.6 USB 2.0.....	10
2.3.7 Ethernet .....	11
2.3.8 Winbond W83627HF .....	13
2.3.9 RICOH R5C551 IEEE1394A Host & PCMCIA Controller .....	13
2.3.10 Compact Flash Interface .....	14
<b>3. HARDWARE CONFIGURATION.....</b>	<b>15</b>
<b>3.1 Installation Procedure.....</b>	<b>15</b>
<b>3.2 Safety Precautions .....</b>	<b>15</b>
3.2.1 Warning! .....	15
3.2.2 Caution!.....	15
<b>3.3 Socket 479 Processor.....</b>	<b>16</b>
3.3.1 Installing Pentium M CPU.....	16
3.3.2 Removing CPU .....	16
<b>3.4 Main Memory .....</b>	<b>16</b>
<b>3.5 Jumper &amp; Connector.....</b>	<b>17</b>
3.5.1 Jumper & Connector Layout .....	17
3.5.2 Jumper & Connector List.....	18
<b>Connectors .....</b>	<b>19</b>
<b>3.6 Setting Jumpers .....</b>	<b>20</b>
3.6.1 Clear CMOS (JBAT).....	21
3.6.2 COM2 RS-232/422/485 Select (JP1, JP2) .....	21
3.6.3 COM1 Pin 9 Signal Select (JP3) .....	21
<b>3.7 Connector Definitions.....</b>	<b>22</b>
3.7.1 ATX Power Connector (ATX) .....	22
3.7.2 Serial Port 1 Connector (COM1) .....	22
3.7.3 Signal Description – Serial Port 1 Connector (COM1).....	23
3.7.4 CPU Fan Connector (FAN1) .....	23
3.7.5 Signal Description – CPU Fan Connector .....	23

3.7.6	Floppy Connector (FLP)	24
3.7.7	Signal Description – Floppy Disk Connector (FLP)	25
3.7.8	Primary IDE Connector (IDE_1)	26
3.7.9	Secondary IDE Connector (IDE_2)	27
3.7.10	Signal Description – IDE Device Connector (IDE_1 / IDE_2)	28
3.7.11	Audio Connector (JAUDIO)	29
3.7.12	Signal Description – Audio Connector (JAUDIO)	29
3.7.13	LCD Inverter Connector (JBKL)	29
3.7.14	Signal Description – LCD Inverter Connector (JBKL)	29
3.7.15	Serial Port 2 Connector (JCOM2)	30
3.7.16	Signal Description – Serial Port 2 Connector in RS-232 Mode (JCOM2)	30
3.7.17	Pin Header Serial Port 2 Connector in RS-422 Mode (JCOM2)	30
3.7.18	Signal Description – Serial Port 2 in RS-422 Mode (JCOM2)	30
3.7.19	Pin Header Serial Port 2 Connector in RS-485 Mode (JCOM2)	31
3.7.20	Signal Description – Serial Port 2 in RS-485 Mode (JCOM2)	31
3.7.21	Front Panel Connector (JFP)	31
3.7.22	IrDA Connector (JIR)	32
3.7.23	Signal Description – IR Connector (JIR)	32
3.7.24	Keyboard and PS/2 mouse connector (JKBMS)	32
3.7.25	Signal Description – Keyboard and PS/2 Mouse Connector (JKBMS)	32
3.7.26	Miscellaneous Setting Connector (JMISC)	33
3.7.27	Signal Description – JMISC Connector	33
3.7.28	LVDS Connector (JLVDS)	34
3.7.29	Signal Description – LVDS Connector (JLVDS)	錯誤! 尚未定義書籤。
3.7.30	TMDS Connector (JTMDS)	35
3.7.31	Signal Description – TMDS Connector (JTMDS)	35
3.7.32	USB Connector (JUSB)	36
3.7.33	Signal Description – USB Connector (JUSB)	36
3.7.34	PS/2 Keyboard & Mouse Connector (KB_MS)	36
3.7.35	Signal Description – PS/2 Keyboard & Mouse Connector	36
3.7.36	10/100 BASE-Tx Ethernet Connector (LAN1/LAN2)	37
3.7.37	Signal Description – 10/100Base-Tx Ethernet Connector	37
3.7.38	10/100/1000 BASE-Tx Ethernet Connector (LAN2: 82540EM Optional)	37
3.7.39	Signal Description – 10/100/1000Base-Tx Ethernet Connector	38
3.7.40	Parallel Port Connector (LPT)	38
3.7.41	DB25 Parallel Port Connector (LPT)	39
3.7.42	Signal Description – Parallel Port (LPT)	40
3.7.43	System Fan Connector 1 (S_FAN1)	40
3.7.44	System Fan Connector 2 (S_FAN2)	40
3.7.45	Signal Description – System Fan Connector	40
3.7.46	VGA Connector (VGA)	41
3.7.47	Signal Description – VGA Connector (VGA)	41
3.7.48	IEEE1394 Port Connector (J1394/1394)	41
3.7.49	Signal Description – IEEE1394 Port Connector (J1394/1394)	41
<b>4.</b>	<b>AWARD BIOS SETUP</b>	<b>42</b>
<b>4.1</b>	<b>Starting Setup</b>	<b>42</b>
<b>4.2</b>	<b>Using Setup</b>	<b>43</b>
4.2.1	Navigating Through The Menu Bar	43
4.2.2	To Display a Sub Menu	43
<b>4.3</b>	<b>Getting Help</b>	<b>44</b>

**ECM-5716 Series**

<b>4.4</b>	<b>In Case of Problems</b> .....	<b>44</b>
<b>4.5</b>	<b>Main Menu</b> .....	<b>44</b>
4.5.1	Setup Items .....	44
4.5.2	Standard CMOS Setup .....	46
4.5.3	Advanced BIOS Features .....	49
4.5.4	Advanced Chipset Features.....	52
4.5.5	Integrated Peripherals.....	54
4.5.6	Power Management Setup.....	57
4.5.7	PnP/PCI Configuration Setup.....	60
4.5.8	PC Health Status.....	62
4.5.9	Frequency / Voltage Control .....	62
4.5.10	Load Fail-Safe Defaults .....	63
4.5.11	Load Optimized Defaults.....	63
4.5.12	Supervisor / User Password Setting.....	64
4.5.13	Exit Selecting .....	65
<b>5.</b>	<b>DRIVER INSTALLATION</b> .....	<b>67</b>
<b>5.1</b>	<b>Driver Installation for Ethernet Adapter</b> .....	<b>67</b>
5.1.1	Windows 9x.....	67
5.1.2	Windows 2000 , XP Ethernet Installation .....	74
<b>5.2</b>	<b>Driver Installation for Display Adapter</b> .....	<b>83</b>
5.2.1	Windows 9x.....	83
5.2.2	Windows 2000 or Windows XP Display Installation .....	86
<b>5.3</b>	<b>Driver Installation for Audio Adapter</b> .....	<b>89</b>
5.3.1	Windows 9x, Windows 2000, Windows XP.....	89
<b>5.4</b>	<b>Driver Installation for Intel 855 Chipset</b> .....	<b>91</b>
<b>6.</b>	<b>POST MESSAGES</b> .....	<b>93</b>
<b>6.1</b>	<b>POST Beep</b> .....	<b>93</b>
<b>6.2</b>	<b>Error Messages</b> .....	<b>93</b>
6.2.1	CMOS BATTERY HAS FAILED .....	93
6.2.2	CMOS CHECKSUM ERROR .....	93
6.2.3	DISK BOOT FAILURE, INSERT SYSTEM DISK AND PRESS ENTER.....	93
6.2.4	DISKETTE DRIVES OR TYPES MISMATCH ERROR - RUN SETUP.....	93
6.2.5	DISPLAY SWITCH IS SET INCORRECTLY .....	94
6.2.6	DISPLAY TYPE HAS CHANGED SINCE LAST BOOT .....	94
6.2.7	EISA Configuration Checksum Error PLEASE RUN EISA CONFIGURATION UTILITY	94
6.2.8	EISA Configuration Is Not Complete PLEASE RUN EISA CONFIGURATION UTILITY	94
6.2.9	ERROR ENCOUNTERED INITIALIZING HARD DRIVE .....	94
6.2.10	ERROR INITIALIZING HARD DISK CONTROLLER.....	94
6.2.11	FLOPPY DISK CNTRLR ERROR OR NO CNTRLR PRESENT .....	94
6.2.12	Invalid EISA Configuration PLEASE RUN EISA CONFIGURATION UTILITY .....	95
6.2.13	KEYBOARD ERROR OR NO KEYBOARD PRESENT .....	95
6.2.14	Memory Address Error at .....	95
6.2.15	Memory parity Error at .....	95
6.2.16	MEMORY SIZE HAS CHANGED SINCE LAST BOOT.....	95
6.2.17	Memory Verify Error at .....	95

6.2.18	OFFENDING ADDRESS NOT FOUND .....	95
6.2.19	OFFENDING SEGMENT:.....	95
6.2.20	PRESS A KEY TO REBOOT .....	96
6.2.21	PRESS F1 TO DISABLE NMI, F2 TO REBOOT .....	96
6.2.22	RAM PARITY ERROR - CHECKING FOR SEGMENT .....	96
6.2.23	Should Be Empty But EISA Board Found PLEASE RUN EISA CONFIGURATION UTILITY.....	96
6.2.24	Should Have EISA Board But Not Found PLEASE RUN EISA CONFIGURATION UTILITY.....	96
6.2.25	Slot Not Empty .....	96
6.2.26	SYSTEM HALTED, (CTRL-ALT-DEL) TO REBOOT .....	96
6.2.27	Wrong Board In Slot PLEASE RUN EISA CONFIGURATION UTILITY .....	97
6.2.28	FLOPPY DISK(S) fail (80) → Unable to reset floppy subsystem.....	97
6.2.29	FLOPPY DISK(S) fail (40) → Floppy Type mismatch.....	97
6.2.30	Hard Disk(s) fail (80) → HDD reset failed.....	97
6.2.31	Hard Disk(s) fail (40) → HDD controller diagnostics failed.....	97
6.2.32	Hard Disk(s) fail (20) → HDD initialization error.....	97
6.2.33	Hard Disk(s) fail (10) → Unable to recalibrate fixed disk.....	97
6.2.34	Hard Disk(s) fail (08) → Sector Verify failed.....	97
6.2.35	Keyboard is locked out - Unlock the key.....	97
6.2.36	Keyboard error or no keyboard present.....	97
6.2.37	Manufacturing POST loop.....	97
6.2.38	BIOS ROM checksum error - System halted.....	97
6.2.39	Memory test fail.....	97
<b>6.</b>	<b>MEASUREMENT DRAWING .....</b>	<b>98</b>
	<b>APPENDIX A: BIOS REVISIONS .....</b>	<b>100</b>
	<b>APPENDIX B: SYSTEM RESOURCES .....</b>	<b>101</b>
	Memory Map .....	101
	I/O – Map .....	102
	Interrupt Usage .....	104
	DMA-channel Usage .....	105
	<b>APPENDIX C: AWARD BIOS POST MESSAGES .....</b>	<b>106</b>
	<b>POST Beep .....</b>	<b>106</b>
	<b>Error Messages .....</b>	<b>106</b>
	CMOS BATTERY HAS FAILED .....	106
	CMOS CHECKSUM ERROR .....	106
	DISK BOOT FAILURE, INSERT SYSTEM DISK AND PRESS ENTER .....	106
	DISKETTE DRIVES OR TYPES MISMATCH ERROR - RUN SETUP .....	106
	DISPLAY SWITCH IS SET INCORRECTLY .....	107
	DISPLAY TYPE HAS CHANGED SINCE LAST BOOT.....	107
	EISA Configuration Checksum Error PLEASE RUN EISA CONFIGURATION UTILITY.....	107
	EISA Configuration Is Not Complete PLEASE RUN EISA CONFIGURATION UTILITY.....	107
	ERROR ENCOUNTERED INITIALIZING HARD DRIVE.....	107
	ERROR INITIALIZING HARD DISK CONTROLLER .....	107
	FLOPPY DISK CNTRLR ERROR OR NO CNTRLR PRESENT.....	107
	Invalid EISA Configuration PLEASE RUN EISA CONFIGURATION UTILITY .....	108
	KEYBOARD ERROR OR NO KEYBOARD PRESENT .....	108

**ECM-5716 Series**

Memory Address Error at .....	108
Memory parity Error at .....	108
MEMORY SIZE HAS CHANGED SINCE LAST BOOT .....	108
Memory Verify Error at .....	108
OFFENDING ADDRESS NOT FOUND.....	108
OFFENDING SEGMENT:.....	108
PRESS A KEY TO REBOOT .....	109
PRESS F1 TO DISABLE NMI, F2 TO REBOOT .....	109
RAM PARITY ERROR - CHECKING FOR SEGMENT .....	109
Should Be Empty But EISA Board Found PLEASE RUN EISA CONFIGURATION UTILITY	109
Should Have EISA Board But Not Found PLEASE RUN EISA CONFIGURATION UTILITY	109
Slot Not Empty .....	109
SYSTEM HALTED, (CTRL-ALT-DEL) TO REBOOT .....	109
Wrong Board In Slot PLEASE RUN EISA CONFIGURATION UTILITY .....	110
FLOPPY DISK(S) fail (80) → Unable to reset floppy subsystem.....	110
FLOPPY DISK(S) fail (40) → Floppy Type mismatch.....	110
Hard Disk(s) fail (80) → HDD reset failed.....	110
Hard Disk(s) fail (40) → HDD controller diagnostics failed. ....	110
Hard Disk(s) fail (20) → HDD initialization error. ....	110
Hard Disk(s) fail (10) → Unable to recalibrate fixed disk. ....	110
Hard Disk(s) fail (08) → Sector Verify failed.....	110
Keyboard is locked out - Unlock the key. ....	110
Keyboard error or no keyboard present. ....	110
Manufacturing POST loop.....	110
BIOS ROM checksum error - System halted.....	110
Memory test fail.....	110
<b>POST CODES.....</b>	<b>111</b>
<b>APPENDIX E: AUDIO / USB DAUGHTER BOARD USER'S GUIDE.....</b>	<b>117</b>
<b>Jumper &amp; Connector Layout .....</b>	<b>錯誤! 尚未定義書籤。</b>
<b>Jumper &amp; Connector List .....</b>	<b>錯誤! 尚未定義書籤。</b>
<b>Measurement Drawing .....</b>	<b>錯誤! 尚未定義書籤。</b>

## Document Amendment History

Revision	Date	By	Comment
1 <sup>st</sup>	Feb. 2004.	Stephen Tsao	Initial Release
2 <sup>nd</sup>	June, 2004	Stephen Tsao	Modify 1. JCOM2 RS422/485 pin definition 2. JTMDS pin 19, 20
3 <sup>rd</sup>	Nov. 2004	Leo Chen	Modify 1. TMDS Connector pin signal 2. Jumper & Connector layout list 3. USB Connector pin define 4. Add in 3.3 Pentium M processor 5. Headquarters address updated. 6. US branch added. 7. Latest BIOS deleted. 8. APPENDIX F: AUDIO / USB DAUGHTER BOARD USER'S MANUAL updated.

## 1. Manual Objectives

This manual describes in detail the Evaluate Technology ECM-5716 series Single Board.

We have tried to include as much information as possible but we have not duplicated information that is provided in the standard IBM Technical References, unless it proved to be necessary to aid in the understanding of this board.

We strongly recommend that you study this manual carefully before attempting to interface with ECM-5716 series or change the standard configurations. Whilst all the necessary information is available in this manual we would recommend that unless you are confident, you contact your supplier for guidance.

Please be aware that it is possible to create configurations within the CMOS RAM that make booting impossible. If this should happen, clear the CMOS settings, (see the description of the Jumper Settings for details).

If you have any suggestions or find any errors concerning this manual and want to inform us of these, please contact our Customer Service department with the relevant details.

## User's Manual

## 2. Introduction

### 2.1 System Overview

The ECM-5716 series is a compact 5.25" CD-ROM size Single Board Computer that equips with Intel Banias Chipset, LCD Interfaces, AC97 Audio, dual 10/100Base-Tx Ethernet, four USB2.0 interfaces, dual IEEE1394 interfaces, PCMCIA, and Compact Flash.

The ECM-5716 series support Intel Pentium M series CPU, which are powerful in performance and low power in system consumption. Its display is bolstered up with the chipset Intel 855GME Integrated graphics which supports LVDS flat panel, DVO, and CRT interfaces. This makes this PC engine a perfect solution for Retail / Financial Transaction Terminals, and high-end multimedia POS / KIOSK Terminals.

Furthermore, the ECM-5716 series is outstanding in a 5.25" form factors designed with Intel 82801DB ICH4 built-in and 82551ER or Intel 82551QM PCI-bus Ethernet 10/100Base-Tx Ethernet controllers (optional an Intel 82540EM PCI-bus Ethernet controller onboard support Gigabit Ethernet function) making it the ideal solution for popular networking devices like Gateway, Router, Thin Server, Firewall and E-Box. In addition, the on board IEEE1394 and 4 USB2.0 interfaces make the ECM-5716 series also ideal for demanding high-end Entertainment Devices that require high integration multimedia Single Board Computer.

Other impressive features include a built-in 40-pin TFT LCD interface (LVDS), a TMDS interface, the AC97 Audio, a Compact Flash socket for type I/ II Compact Flash storage card, one parallel port, one PCMCIA socket, and one 184-pin DDR SDRAM DIMM sockets allowing for up to 1GB of DDR SDRAM to be installed, and a PCI slot for future expansion.

## 2.2 System Specifications

### General Functions

- **CPU:** Supports Intel Pentium-M series processors
- **BIOS:** Award 512 KB FWH BIOS
- **Chipset:** Intel 855GME + Intel 82801DB (ICH4)
- **I/O Chipset:** Winbond W83627HF-AW
- **Memory:** Onboard one DDR SDRAM socket supports up to 1 Gbytes DDR 333/266/200 SDRAM
- **Enhanced IDE:** Supports up to four IDE devices. Supports Ultra DMA/100 mode with data transfer rate up to 100MB/sec. (Primary: 20 x 2 box header; Secondary: 22 x 2, pitch 2.0mm box header onboard for DiskOnModule)
- **FDD Interface:** Supports up to two floppy disk drives, 5.25" (360KB and 1.2MB) and /or 3.5" (720KB, 1.44MB, and 2.88MB). Supports Mode-3 FDD
- **Parallel Port:** An Internal header for bi-directional parallel port x 1. Supports SPP, ECP, and EPP modes
- **Serial Port:** Supports Two RS-232 serial ports. Ports can be configured as COM1, COM2, COM3, COM4, or disabled individually. (16C550 equivalent) (COM1 with D-Sub 9, COM2 with 5 x 2, pitch 2.54 box header) COM2 can be set as RS-232/422/485.
- **IR Interface:** Supports one IrDA Tx/Rx header
- **KB/Mouse Connector:** External mini-DIN PS2 Keyboard/Mouse connector x 1, Internal KB/Mouse connector 4X2 header pitch 2.54mm
- **USB 2.0 Connectors:** Two external USB 2.0 connectors. One 5 x 2, pitch 2.54mm header supports additional dual USB 2.0
- **Watchdog Timer:** Can generate a system reset, IRQ10/11 or NMI. Software selectable time out interval (1 sec. ~ 255 min., 1 sec. or 1 min. /step)
- **Power Management:** Supports ATX power supply. Supports PC97, LAN wake up and modem ring-in functions. I/O peripheral devices support power saving and doze/standby/suspend modes. ACPI 2.0 & APM 1.2 compliant.

## User's Manual

### ***IEEE1394 Interface***

- **Chipset:** RICOH R5C551
- **IEEE1394 Interface:** Integrated 400 Mbit 2-Port PHY supports 2 IEEE1394A Ports

### ***Flat Panel/CRT Interface***

- **Chipset:** Intel 855 Chipset Graphics Memory Controller Hub (GMCH) integrated AGP high performance 256-bit GUI, 3D engine
- **Display Memory:** Programmable frame buffer size up to 64MBytes
- **Display Type:** Simultaneously supports CRT and TFT displays
- **Resolution:** CRT displays support up to 1600 x 1200 @ 85-Hz

### ***PanelLink Interface***

- **Chipset:** **Chrontel** CH7301A DVI / TV output device
- **Display Type:** DVI display at a pixel rate of up to 165MHz, supporting UXGA resolution displays.

### ***LVDS Interface***

- **Chipset:** Intel 855GME Chipset
- **Display Memory:** Programmable frame buffer size up to 64MBytes
- **Display Type:** 24-bit to 48-bit flat panel displays
- **Scalable bandwidth:** Single or dual channel LVDS panel support up to UXGA panel solution with frequency range from 25 MHz to 112 MHz per channel.

### ***Audio Interface***

- **Chipset:** Intel ICH4 integrated Audio controller with AC97 interface
- **AC97 Codec:** VIA VT1616
- **Audio Controller:** AC97 ver. 2.3 compliant interface. Supports Audio Out (5.1channel playback)

### ***Ethernet Interface***

- **Chipset:** Intel 82801DB (ICH4) built-in and 82551ER PCI-bus Ethernet controller onboard support dual Ethernet function
- **Ethernet Interface:** PCI 100/10 Mbps, IEEE 802.3U compatible

### ***Gigabit Ethernet Interface (Optional)***

- **Chipset:** Intel 82540EM PCI-bus Ethernet controller onboard support Gigabit Ethernet function
- **Ethernet Interface:** PCI 1000/100/10 Mbps, IEEE 802.3x compatible.

### ***SSD Interface***

One CF socket supports Type I/II Compact Flash memory devices

### ***Expansion Interface***

- **PCI Slot:** One 32-bit PCI slot onboard


### ***Mechanical and Environmental***

- **Power Supply Voltage:** ATX type, +5V and +12V
- **Operating Temperature:** 32 to 140°F (0 to 60°C)
- **Board Size:** 8"(L) x 5.75"(W) (203mm x 146mm)
- **Weight:** 0.5 Kg

## User's Manual

### 2.3 Architecture Overview

The following block diagram shows the architecture and main components of ECM-5716 series.



The following sections provide detail information about the functions provided onboard.

### 2.3.1 855GME and 82801DB

The Intel 855GM/855GME GMCH components provide the processor interface, DDR SDRAM interface, display interface, and Hub interface. The Intel 855GME also has an option for AGP external graphics port, in addition to integrated graphics support for added board flexibility options.

The Intel 855GM GMCH is in a 732-pin Micro-FCBGA package and contains the following functionality listed below:

- AGTL+ host bus supporting 32-bit host addressing with Enhanced Intel SpeedStep technology support

- Supports a single channel of DDR SDRAM memory

- System memory supports DDR200/266 MHz (SSTL\_2) DDR SDRAM

- Integrated graphics capabilities: Display Core frequency at 133 MHz or 200 MHz

- Render Core frequency at 100 MHz, 133 MHz, and 200 MHz

- Provides supports four display ports: one progressive scan analog monitor, dual channel LVDS interface and two DVO port.

The Intel 855GME GMCH is in a 732-pin Micro-FCBGA package and contains all features listed above and the additional functionality list below:

- Display Core frequency at 133 MHz, 200 MHz, or 250 MHz

- Render Core frequency at 100 MHz, 133 MHz, 166 MHz, 200 MHz, or 250 MHz

- System memory supports 200/266/333- MHz (SSTL\_2) DDR SDRAM.

- Enhanced Power Management Graphics features

The GMCH IGD provides a highly integrated graphics accelerator delivering high performance 2D, 3D, and video capabilities. With its interfaces to UMA using a DVMT configuration, an analog display, a LVDS port, and two digital display ports (e.g. flat panel), the GMCH can provide a complete graphics solution.

The GMCH also provides 2D hardware acceleration for block transfers of data (BLTs). The BLT engine provides the ability to copy a source block of data to a destination and perform raster operations (e.g., ROP1, ROP2, and ROP3) on the data using a pattern, and/or another destination. Performing these common tasks in hardware reduces CPU load, and thus improves performance. High bandwidth access to data is provided through the system memory interface. The GMCH uses Tiling architecture to increase system memory efficiency and thus maximize effective rendering bandwidth. The Intel 855GM/855GME GMCH improves 3D performance and quality with 3D Zone rendering technology. The Intel 855GME GMCH also supports Video Mixer rendering, and Bi-Cubic filtering.

The Intel 855GM/855GME GMCH has four display ports, one analog and three digital. With these interfaces, the GMCH can provide support for a progressive scan analog monitor, a dedicated dual channel LVDS LCD panel, and two DVO devices. Each port can transmit data according to one or more protocols. The data that is sent out the display port is selected from one of the two possible sources, Pipe A or Pipe B.

## User's Manual

The Intel 855GM/855GME GMCH have an integrated dual channel LFP Transmitter interface to support LVDS LCD panel resolutions up to UXGA. The display pipe provides panel up-scaling to fit a smaller source image onto a specific native panel size, as well as provides panning and centering support. The LVDS port is only supported on Pipe B. The LVDS port can only be driven by Pipe B, either independently or simultaneously with the Analog Display port. Spread Spectrum Clocking is supported: center and down spread support of 0.5%, 1%, and 2.5% utilizing an external SSC clock.

The DVO B/C interface is compliant with the DVI Specification 1.0. When combined with a DVI compliant external device (e.g. TMDS Flat Panel Transmitter, TV-out encoder, etc.), the GMCH provides a high-speed interface to a digital or analog display (e.g. flat panel, TV monitor, etc.). The DVO ports are connected to an external display device. Examples of this are TV-out encoders, external DACs, LVDS transmitters, and TMDS transmitters. Each display port has control signals that may be used to control, configure and/or determine the capabilities of an external device. The GMCH provides two DVO ports that are each capable of driving a 165-MHz pixel clock at the DVO B or DVO C interface. When DVO B and DVO C are combined into a single DVO port, then an effective pixel rate of 330 MHz can be achieved. The DVO B/C ports can be driven by Pipe A or Pipe B. If driven on Pipe B, then the LVDS port must be disabled.

The ICH4 is a highly integrated multifunctional I/O Controller Hub that provides the interface to the PCI Bus and integrates many of functions needed in today's PC platform. The GMCH and ICH4 communicate over a dedicated hub interface. The 82801DB ICH4 functions and capabilities include:

- PCI Rev. 2.2 compliant with support for 33MHz PCI operations
- Supports up to 6 Request/Grant pairs (PCI slots)
- Power management logic support
- Enhanced DMA controller, interrupt controller, and timer functions
- Integrated IDE controller; Ultra ATA/100/66/33
- USB host interface; 3 host controllers and supports 6 USB ports; includes a EHCI high-speed 2.0 USB controller
- Integrated LAN controller
- System Management Bus (SMBus) compatible with most IC devices; ICH4 has both bus master and slave capability
- AC '97 2.3 compliant link for audio and telephony codecs; up to 6 channels
- Low Pin Count (LPC) interface
- FWH Interface (FWH Flash BIOS support)
- Alert on LAN\* (AOL and AOL2)

### 2.3.2 DRAM Interface

The GMCH system memory controller directly supports the following:

- One channel of PC1600/2100 SO-DIMM DDR SDRAM memory (Intel 855GM GMCH)

- One channel of PC1600/2100/2700 SO-DIMM DDR SDRAM memory (Intel 855GME GMCH)

- DDR SDRAM devices with densities of 128-Mb, 256-Mb, and 512-Mb technology

- Up to 1 GB (512-Mb technology) with two SO-DIMMs

- Up to 2 GB (512-Mb technology) using high density devices with two SO-DIMMs

### 2.3.3 Chrontel CH7301 DVI Transmitter

The Chrontel CH7301 is a display controller device which accepts a digital graphics input signal, and encodes and transmitter data through a DVI or DFP (Digital flat panel). The device accepts data over one 12-bit wide variable voltage data port which supports four different RGB data formats. The DVI processor includes a low jitter PLL for generation of the high frequency serialized clock, and all circuitry required to decode, serialized and transmit data. The CH7301 comes in versions able to drive a DFP display at a pixel arte up to 165MHz, supporting UXGA resolution displays. No scaling of input data is performed on the data output to the DVI device.

### 2.3.4 PCI Interface

The ICH4 PCI interface provides a 33 MHz, Rev. 2.2 compliant implementation. All PCI signals are 5V tolerant, except PME#. The ICH2 integrates a PCI arbiter that supports up to six external PCI bus masters in addition to the internal ICH4 requests.

### 2.3.5 IDE Interface (Bus Master Capability and Synchronous DMA Mode)

The fast IDE interface supports up to four IDE devices providing an interface for IDE hard disks and ATAPI devices. Each IDE device can have independent timings. The IDE interface supports PIO IDE transfers up to 16 Mbytes/sec and Ultra ATA transfers up to 100 Mbytes/sec. It does not consume any ISA DMA resources. The IDE interface integrates 16x32-bit buffers for optimal transfers.

The ICH4's IDE system contains two independent IDE signal channels. They can be electrically isolated independently. They can be configured to the standard primary and secondary channels (four devices). There are integrated series resistors on the data and control lines.

Access to these controllers is provided by two standard IDC 40-pin connectors.

## User's Manual

### 2.3.6 USB 2.0

The ICH4 contains an Enhanced Host Controller Interface (EHCI) compliant host controller that supports USB high-speed signaling. High-speed USB 2.0 allows data transfers up to 480Mb/s which is 40 times faster than full-speed USB. The ICH4 also contains three Universal Host Controller Interface (UHCI) controllers that support USB full-speed and low-speed signaling.

The ICH4 supports 6 USB 2.0 ports. All six USB ports are high-speed, full-speed, and low-speed capable. ICH4's port-routing logic determines whether a USB port is controlled by one of the UHCI controllers or by the EHCI controller.

## 2.3.7 Ethernet

### 2.3.7.1 ICH4 LAN Controller

ICH4's integrated LAN Controller includes a 32-bit PCI controller that provides enhanced scatter-gather bus mastering capabilities and enables the LAN Controller to perform high-speed data transfers over the PCI bus. Its bus master capabilities enable the component to process high level commands and perform multiple operations, this lowers processor utilization by off-loading communication tasks from the processor. Two large transmit and receive FIFOs of 3 KB each help prevent data under runs and overruns while waiting for bus accesses. This enables the integrated LAN Controller to transmit data with minimum interframe spacing (IFS).

The LAN Controller can operate in either full duplex or half duplex mode. In full duplex mode the LAN Controller adheres with the IEEE 802.3x Flow Control specification. Half duplex performance is enhanced by a proprietary collision reduction mechanism.

The integrated LAN controller also includes an interface to a serial (4-pin) EEPROM. The EEPROM provides power-on initialization for hardware and software and software configuration parameters.

From a software perspective, the integrated LAN controller appears to reside on the secondary side of the ICH4's virtual PCI to PCI Bridge. This is typically Bus 1, but may be assigned a different number, depending on system configuration.

The following summarizes the ICH4 LAN controller features:

- *Compliance with Advanced Configuration and Power Interface and PCI Power Management standard.*
- *Support for wake-up on interesting packets and link status change*
- *Support for remote power-up using Wake on LAN (WOL) technology*
- *Deep power-down node support*
- *Support of Wired for management (WfM) Rev 2.0*
- *Backward compatible software with 82447, 82558 and 82559*
- *TCP/UDP checksum offload capabilities*
- *Support for Intel's Adaptive Technology*

## User's Manual

### 2.3.7.2 Intel 82551ER Ethernet Controller

The Intel® 82551ER Integrated 10BASE-T/100BASE-TX Ethernet Controller expands the family of Intel® 8255x controllers. As part of Intel's fourth generation of fully integrated Fast Ethernet MAC/PHY solutions, the 82551ER is optimized for low-cost, embedded applications. The 82551ER provides excellent performance with offloading of TCP, UDP and IP checksums. Its optimized 32-bit interface and efficient scatter-gather bus mastering capabilities enable the controller to perform high-speed data transfers over the PCI bus. These capabilities accelerate the processing of high-level commands and operations, lowering CPU utilization. The device's architecture enables efficient data flow from the bus interface unit to the 3KB transmit and receive FIFOs, providing the perfect balance between the wire and system bus. In addition, multiple priority queues augment Quality of Service (QoS) performance. The 82551ER is pin-compatible with the Intel® 82559ER Fast Ethernet controller, and it is layoutcompatible with Intel® 82540 Gigabit Ethernet controller. Intel-supported 82551ER drivers run on the standard Intel® 82551QM Fast Ethernet PCI/CardBus Controller, providing OEMs an upgrade path to the 82551QM for additional features and increased functionality.

### 2.3.7.3 Intel 82540EM Ethernet Controller (Optional)

The Intel 82540EM Gigabit Ethernet Controller is a single, compact component with an integrated Gigabit Ethernet Media Access Control (MAC) and physical layer (PHY) functions. For desktop, workstation and mobile PC network designs with critical space constraints, the Intel 82540EM allows for a Gigabit Ethernet implementation in a very small area that is footprint compatible with current 10/100 Mbps Fast Ethernet designs.

The Intel 82540EM integrates Intel's fourth generation gigabit MAC design with fully integrated, physical layer circuitry to provide a standard IEEE 802.3 Ethernet interface for 1000BASE-T, 100BASE-TX, and 10BASE-T applications (802.3, 802.3u, and 802.3ab). The controller is capable of transmitting and receiving data at rates of 1000M bps, 100 Mbps, or 10 Mbps. In addition to managing MAC and PHY layer functions, the controller provides a 32-bit wide direct Peripheral Component Interconnect (PCI) 2.2 compliant interface capable of operating at 33 or 66 MHz.

The Intel 82540EM's on-board System Management Bus (SMB) port enables network manageability implementations required by information technology personnel for remote control and alerting via the LAN. With SMB, management packets can be routed to or from a management processor. The SMB port enables industry standard, such as Intelligent Platform Management Interface (IPMI) and Alert Standard Forum (ASF), to be implemented using the 82540EM. In addition, on chip ASF 1.0 circuitry provides alerting and remote control capabilities with standardized interfaces.

The 82540EM Gigabit Ethernet Controller architecture is designed to deliver high performance and PCI bus efficiency. Wide internal data paths eliminate performance bottlenecks by efficiently handling large address and data words. The 82540EM controller includes advanced interrupt handling features to limit PCI bus traffic and a PCI interface that maximizes the use of bursts for efficient PCI bandwidth use. A large 64 KByte on-chip packet buffer maintains superior performance as available PCI bandwidth changes. In addition, using hardware acceleration, the controller offloads tasks from the host controller, such as TCP/UDP/IP checksum calculations and TCP segmentation.

The 82540EM is packed in a 15mm<sup>2</sup> 196-ball grid array and is pin compatible with the Intel 82551QM 10/100 Mbps Fast Ethernet Multifunction PCI/CardBus Controller.

### 2.3.8 Winbond W83627HF

The Winbond W83627F/HF is made to fully comply with Microsoft PC98 and PC99 Hardware Design Guide. Moreover, W83627F/HF is made to meet the specification of PC98/PC99's requirement in the power management: ACPI and DPM (Device Power Management). Super I/O chip provides features as the following:

- Meet LPC Spec. 1.0
- Support LDRQ# (LPC DMA), SERIRQ (serial IRQ)
- Include all features of Winbond I/O W83977TF and W83977EF
- Integrate Hardware Monitor functions
- Compliant with Microsoft PC98/PC99 Hardware Design Guide.
- Support DPM (Device Power Management), ACPI
- Programmable configuration settings
- Single 24 or 48 MHz clock input

### 2.3.9 RICOH R5C551 IEEE1394A Host & PCMCIA Controller

The 5C551 is the single chip solution offering PCI bus-PC Card bridges and PCI bus-IEEE 1394 OHCI bridge with integrated PHY. The R5C551 is compliant with the latest specification in both PC card and IEEE 1394.

The R5C551 has two PCI functions compliant, the PC card interface and the IEEE1394 interface. The PC card controller of the R5C551 is compliant with PC Card Standard Release 7.0. The R5C551 provides features that make it the best choice for bridging between the PCI bus PC Cards, and supports any combination of 16-bit (Card-16) and CardBus (Card-32) PC Cards in one socket, powered at 5V or 3.3V, as required.

The R5C551's 16-bit card control register is compatible with the Intel 82365SL and Ricoh's RF5C396/366 in order to maintain backward compatibility with the existing 16-bit PC Card compliant with PCMCIA2.1/JEIDA4.2. All PC card interface signals are individually buffered to allow direct connection to CardBus and Hot Insertion/Removal without external buffers. The R5C551 also allows direct connection to PCI bus.

The R5C551 provides the IEEE1394 OHCI-Link and two ports the IEEE1394 PHY that are compliant with the IEEE1394 -1995, IEEE1394a-2000 and the latest 1394 OHCI specifications (Release 1.1/1.0). The R5C551 data rate is capable of 100/200, and 400Mbits per second. The R5C551 has the large FIFO buffer and the DMA engine, which work independently to achieve the high speed transmission rate. The R5C551 is compliant with the latest PCI Bus Power Management Specification, and provides several low-power modes that enable the host power system to further reduce power consumption.

## User's Manual

### 2.3.10 Compact Flash Interface

A Compact Flash type II connector is connected to the secondary IDE controller. The Compact Flash storage card is IDE compatible. It is an ideal replacement for standard IDE hard drives. The solid-state design offers no seek errors even under extreme shock and vibration conditions. The Compact Flash storage card is extremely small and highly suitable for rugged environments, thus providing an excellent solution for mobile applications with space limitations. It is fully compatible with all consumer applications designed for data storage PC card, PDA, and Smart Cellular Phones, allowing simple use for the end user. The Compact Flash storage card is O/S independent, thus offering an optimal solution for embedded systems operating in non-standard computing environments. The Compact Flash storage card is IDE compatible and offers various capacities.

### 3. Hardware Configuration

This chapter explains you the instructions of how to setup your system.

#### 3.1 Installation Procedure

1. Turn off the power supply.
2. Insert the DIMM module (be careful with the orientation).
3. Insert all external cables for hard disk, floppy, keyboard, mouse, USB etc. except for flat panel. A CRT monitor must be connected in order to change CMOS settings to support flat panel.
4. Connect power supply to the board via the PWR1.
5. Turn on the power.
6. Enter the BIOS setup by pressing the delete key during boot up. Use the “LOAD BIOS DEFAULTS” feature. The **Integrated Peripheral Setup** and the **Standard CMOS Setup** Window must be entered and configured correctly to match the particular system configuration.
7. If TFT panel display is to be utilised, make sure the panel voltage is correctly set before connecting the display cable and turning on the power.

#### 3.2 Safety Precautions

##### 3.2.1 Warning!



Always completely disconnect the power cord from your chassis or power cable from your board whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

##### 3.2.2 Caution!



Always ground yourself to remove any static charge before touching the board. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

## User's Manual

### 3.3 Socket 479 Processor

#### 3.3.1 Installing Pentium M CPU

- Align the processor pins with pin holes on the socket. Make sure that the notched corner or dot mark (pin 1) of the CPU corresponds to the socket's bevel end. Then press the CPU gently until it fits into place. If this operation is not easy or smooth, don't do it forcibly. You need to check and rebuild the CPU pin uniformly.
- Use a screw driver to revolve the screw till the processor chip is locked into the socket.
- Follow the installation guide of cooling fan or heat sink to mount it on CPU surface and lock it on the socket 479.
- Be sure to follow particular CPU speed and voltage type to adjust the jumper settings properly.

#### 3.3.2 Removing CPU

- Unlock the cooling fan first.
- Lift the lever of CPU socket outwards and upwards to the other end.
- Carefully lift up the existing CPU to remove it from the socket.
- Follow the steps of installing a CPU to change to another one or place handling bar to close the opened socket.

### 3.4 Main Memory

ECM-5716 provides one 184-pin DDR SDRAM DIMM sockets to support DDR SDRAM. The total maximum memory size is 1GB.


Watch out the contact and lock integrity of memory module with socket, it will influence the system's reliability. Follow the normal procedure to install your DDR SDRAM module into the DIMM socket. Before locking the DIMM module, make sure that the memory module has been completely inserted into the DIMM socket.

#### Note:

Please do not change any DDR SDRAM parameter in BIOS setup to increase your system's performance without acquiring technical information in advance.

### 3.5 Jumper & Connector

#### 3.5.1 Jumper & Connector Layout



## User's Manual

### 3.5.2 Jumper & Connector List

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

The following tables list the function of each of the board's jumpers and connectors.

<b>JBAT</b>	Clear CMOS	3 x 1 header, pitch 2.54mm
<b>JP1, JP2</b>	COM2 RS-232/422/485 select	3 x 2 header, pitch 2.54mm 4 x 3 header, pitch 2.54mm (JP1)
<b>JP3</b>	COM1 pin 9 signal select	3 x 2 header, pitch 2.54mm


<b>Connectors</b>		
<b>Label</b>	<b>Function</b>	<b>Note</b>
<b>ATXPWR</b>	ATX Power connector	ATX power connector
<b>COM1</b>	Serial port 1 connector	9-pin male D-sub connector
<b>DIMM1</b>	184-pin DIMM socket	
<b>C_FAN1</b>	CPU fan connector	3 x 1 wafer, pitch 2.54mm
<b>FLP</b>	Floppy connector	17 x 2 header, pitch 2.54mm
<b>IDE_1</b>	Primary IDE connector	20 x 2 header, pitch 2.54mm
<b>IDE_2</b>	Secondary IDE connector	22 x 2 header, pitch 2.0mm
<b>JAUDIO</b>	Audio connector	8 x 2 header, pitch 2.0mm
<b>JBKL</b>	LCD inverter connector	5 x 1 wafer, pitch 2.0mm
<b>JCOM2</b>	Serial port 2 connector	5 x 2 header, pitch 2.54mm
<b>JFP</b>	Front panel connector	8 x 2 header, pitch 2.54mm
<b>JIR</b>	IrDA connector	5 x 1 header, pitch 2.54mm
<b>JKBMS</b>	Keyboard and PS/2 mouse connector	4 x 2 header, pitch 2.54mm
<b>JMISC</b>	Miscellaneous Setting Connector	5 x 2 header, pitch 2.54mm
<b>JLVDS</b>	LVDS connector	HIROSE DF13-40DP-1.25V
<b>JTMDS</b>	TMDS connector	HIROSE DF13-20DP-1.25V
<b>JUSB</b>	USB connector	5 x 2 header, pitch 2.54mm
<b>J1394</b>	IEEE1394 port 2 connector	
<b>KB_MS</b>	Keyboard and PS/2 mouse connector	6-pin mini Din
<b>LAN1</b>	10/100Base-Tx Ethernet 1 connector	RJ-45
<b>LAN2</b>	10/100Base-Tx Ethernet 1 connector	RJ-45
<b>LPT</b>	Parallel port connector	13 x 2 header, pitch 2.54mm
<b>PCI</b>	PCI connector	
<b>S_FAN1</b>	System fan connector 1	3 x 1 wafer, pitch 2.54mm
<b>S_FAN2</b>	System fan connector 2	3 x 1 wafer, pitch 2.54mm
<b>USB</b>	USB connector	
<b>VGA</b>	VGA connector	15-pin female D-sub connector
<b>1394</b>	IEEE1394 port 1 connector	

## User's Manual


### 3.6 Setting Jumpers

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

### 3.6.1 Clear CMOS (JBAT)

You can use JBAT to clear the CMOS data if necessary. To reset the CMOS data, set JBAT to 2-3 closed for just a few seconds, and then move the jumper back to 1-2 closed.

Clear CMOS (JBAT)		
	Protect*	Clear CMOS
JBAT		

\* default

### 3.6.2 COM2 RS-232/422/485 Select (JP1, JP2)

The ECM-5716 COM2 serial port can be selected as RS-232, RS-422, or RS-485 by setting JP1 & JP2.

COM2 Select (JP1, JP2)			
	RS-232*	RS-422	RS-485
JP2			
JP1			

\* default

### 3.6.3 COM1 Pin 9 Signal Select (JP3)

The ECM-5716 COM1 pin 9 signal can be selected as +12V, +5V, or Ring by setting JP3.

COM1 Select (JP3)			
	Ring*	+5V	+12V
JP3			

\* default

## User's Manual

## 3.7 Connector Definitions

## 3.7.1 ATX Power Connector (ATX)

Signal	PIN		Signal
3.3V	11	1	3.3V
-12V	12	2	3.3V
GND	13	3	GND
PS-ON	14	4	+5V
GND	15	5	GND
GND	16	6	+5V
GND	17	7	GND
-5V	18	8	PWROK
+5V	19	9	5V SB
+5V	20	10	+12V

## 3.7.2 Serial Port 1 Connector (COM1)

Signal	PIN		Signal
DCD	1		
		6	DSR
RxD	2		
		7	RTS
TxD	3		
		8	CTS
DTR	4		
		9	RI
GND	5		

**3.7.3 Signal Description – Serial Port 1 Connector (COM1)**

TxD	Serial output. This signal sends serial data to the communication link. The signal is set to a marking state on hardware reset when the transmitter is empty or when loop mode operation is initiated.
RxD	Serial input. This signal receives serial data from the communication link.
DTR	Data Terminal Ready. This signal indicates to the modem or data set that the on-board UART is ready to establish a communication link.
DSR	Data Set Ready. This signal indicates that the modem or data set is ready to establish a communication link.
RTS	Request To Send. This signal indicates to the modem or data set that the on-board UART is ready to exchange data.
CTS	Clear To Send. This signal indicates that the modem or data set is ready to exchange data.
DCD	Data Carrier Detect. This signal indicates that the modem or data set has detected the data carrier.
RI	Ring Indicator. This signal indicates that the modem has received a telephone ringing signal.

**3.7.4 CPU Fan Connector (FAN1)**

SIGNAL	PIN
TAC	3
+12V	2
GND	1

**3.7.5 Signal Description – CPU Fan Connector**

TAC	Fan speed monitor
-----	-------------------

## User's Manual

## 3.7.6 Floppy Connector (FLP)

Signal	PIN		Signal
DSKCHG#	34	33	GND
SIDE1#	32	31	GND
RDATA#	30	29	GND
WPT#	28	27	GND
TRAK0#	26	25	GND
WE#	24	23	GND
WD#	22	21	GND
STEP#	20	19	GND
DIR#	18	17	GND
MOB#	16	15	GND
DSA#	14	13	GND
DSB#	12	11	GND
MOA#	10	9	GND
INDEX#	8	7	GND
NC	6	5	GND
NC	4	3	GND
DRV DEN0#	2	1	GND

**3.7.7 Signal Description – Floppy Disk Connector (FLP)**

RDATA#	The read data input signal from the FDD.
WD#	Write data. This logic low open drain writes pre-compensation serial data to the selected FDD. An open drain output.
WE#	Write enable. An open drain output.
MOA#	Motor A On. When set to 0, this pin enables disk drive 0. This is an open drain output.
MOB#	Motor B On. When set to 0, this pin enables disk drive 1. This is an open drain output.
DSA#	Drive Select A. When set to 0, this pin enables disk drive A. This is an open drain output.
DSB#	Drive Select B. When set to 0, this pin enables disk drive B. This is an open drain output.
SIDE1#	This output signal selects side of the disk in the selected drive.
DIR#	Direction of the head step motor. An open drain output Logic 1 = outward motion Logic 0 = inward motion
STEP#	Step output pulses. This active low open drain output produces a pulse to move the head to another track.
DRVDEN0#	This output indicates whether a low drive density (250/300kbps at low level) or a high drive density (500/1000kbps at high level) has been selected.
TRAK0#	Track 0. This Schmitt-triggered input from the disk drive is active low when the head is positioned over the outermost track.
INDEX#	This Schmitt-triggered input from the disk drive is active low when the head is positioned over the beginning of a track marked by an index hole.
WP#	Write protected. This active low Schmitt input from the disk drive indicates that the diskette is write-protected.
DSKCHG#	Diskette change. This signal is active low at power on and whenever the diskette is removed.

## User's Manual

## 3.7.8 Primary IDE Connector (IDE\_1)

Signal	PIN		Signal
RESET#	1	2	GND
PDD7	3	4	PDD8
PDD6	5	6	PDD9
PDD5	7	8	PDD10
PDD4	9	10	PDD11
PDD3	11	12	PDD12
PDD2	13	14	PDD13
PDD1	15	16	PDD14
PDD0	17	18	PDD15
GND	19	20	NC
PDREQ	21	22	GND
PDIOW#	23	24	GND
PDIOR#	25	26	GND
PIORDY	27	28	GND
PDDACK#	29	30	GND
IRQ14	31	32	NC
PDA1	33	34	NC
PDA0	35	36	PDA2
PDCS1#	37	38	PDCS3#
IDEACTP#	39	40	GND

**3.7.9 Secondary IDE Connector (IDE\_2)**

Signal	PIN		Signal
RESET#	1	2	GND
SDD7	3	4	SDD8
SDD6	5	6	SDD9
SDD5	7	8	SDD10
SDD4	9	10	SDD11
SDD3	11	12	SDD12
SDD2	13	14	SDD13
SDD1	15	16	SDD14
SDD0	17	18	SDD15
GND	19	20	NC
SDREQ	21	22	GND
SDIOW#	23	24	GND
SDIOR#	25	26	GND
SIORDY	27	28	GND
SDDACK#	29	30	GND
IRQ15	31	32	NC
SDA1	33	34	NC
SDA0	35	36	SDA2
SDCS1#	37	38	SDCS3#
IDEACTS#	39	40	GND
VCC	41	42	VCC
GND	43	44	NC

## User's Manual

**3.7.10 Signal Description – IDE Device Connector (IDE\_1 / IDE\_2)**

The IDE interface supports PIO modes 0 to 4 and Bus Master IDE. Data transfer rates up to 100 MB/Sec is possible.

DA [2:0]	IDE Address Bits. These address bits are used to access a register or data port in a device on the IDE bus.
DCS1#, DCS3#	IDE Chip Selects. The chip select signals are used to select the command block registers in an IDE device. DCS1# selects the primary hard disk.
D [15:0]	IDE Data Lines. D [15:0] transfers data to/from the IDE devices.
IOR#	IDE I/O Read. Signal is asserted on read accesses to the corresponding IDE port addresses.
IOW#	IDE I/O Write. Each signal is asserted on write accesses to corresponding the IDE port addresses.
IRDY	When deasserted, these signals extend the transfer cycle of any host register access when the device is not ready to respond to the data transfer request.
RESET#	IDE Reset. This signal resets all the devices that are attached to the IDE interface.
IRQ14	Interrupt line from hard disk. Connected directly to PC-AT bus.
DREQ	The DREQ is used to request a DMA transfer from the South Bridge. The direction of the transfers is determined by the IOR#/IOW# signals.
DACK#	DMA Acknowledge. The DACK# acknowledges the DREQ request to initiate DMA transfers.
DACT#	Signal from hard disk indicating hard disk activity. The signal level depends on the hard disk type, normally active low. The signal is routed directly to the LED1.

**3.7.11 Audio Connector (JAUDIO)**

Signal	PIN		Signal
Mic_In	1	2	AREF
AUDGND	3	4	AUDGND
Line_Out L	5	6	Line_Out R
SPK R	7	8	SPK L
Line_In L	9	10	Line_In R
AUDGND	11	12	Reserved
GND	13	14	Reserved
GND	15	16	Reserved

**3.7.12 Signal Description – Audio Connector (JAUDIO)**

SPK L/R	Left and right speaker output. These are the speaker outputs directly from the speaker amplifier.
Mic_In	The MIC signal is used for microphone input. This input is fed to the left microphone channel.
Line-In L/R	Left and right line in signals.
Line-Out L/R	Left and right line out signals. Both signals are capacitor coupled and should have GND as return.

**3.7.13 LCD Inverter Connector (JBKL)**

Signal	PIN
+12V	1
GND	2
ENBKL	3
Bright	4
VCC	5

**3.7.14 Signal Description – LCD Inverter Connector (JBKL)**

Bright	Bright Adjust
ENBKL	LCD backlight ON/OFF control signal.

## User's Manual

**3.7.15 Serial Port 2 Connector (JCOM2)**

Signal	PIN		Signal
DCD	1	2	RXD
TXD	3	4	DTR
GND	5	6	DSR
RTS	7	8	CTS
NRI	9	10	NC

**3.7.16 Signal Description – Serial Port 2 Connector in RS-232 Mode (JCOM2)**

TxD	Serial output. This signal sends serial data to the communication link. The signal is set to a marking state on hardware reset when the transmitter is empty or when loop mode operation is initiated.
RxD	Serial input. This signal receives serial data from the communication link.
DTR	Data Terminal Ready. This signal indicates to the modem or data set that the on-board UART is ready to establish a communication link.
DSR	Data Set Ready. This signal indicates that the modem or data set is ready to establish a communication link.
RTS	Request To Send. This signal indicates to the modem or data set that the on-board UART is ready to exchange data.
CTS	Clear To Send. This signal indicates that the modem or data set is ready to exchange data.
DCD	Data Carrier Detect. This signal indicates that the modem or data set has detected the data carrier.
RI	Ring Indicator. This signal indicates that the modem has received a telephone ringing signal.

**3.7.17 Pin Header Serial Port 2 Connector in RS-422 Mode (JCOM2)**

Signal	PIN		Signal
TX-	1	2	RX+
TX+	3	4	RX-
GND	5	6	NC
NC	7	8	NC
NC	9	10	NC

**3.7.18 Signal Description – Serial Port 2 in RS-422 Mode (JCOM2)**

Tx +/-	Serial output. This differential signal pair sends serial data to the communication link. Data is transferred from Serial Port 2 Transmit Buffer Register to the communication link, if the RTS register of the Serial Port 2 is set to LOW.
Rx +/-	Serial input. This differential signal pair receives serial data from the communication link. Received data is available in Serial Port 2 Receiver Buffer Register.

**3.7.19 Pin Header Serial Port 2 Connector in RS-485 Mode (JCOM2)**

Signal	PIN		Signal
TX-	1	2	NC
TX+	3	4	NC-
GND	5	6	NC
NC	7	8	NC
NC	9	10	NC

**3.7.20 Signal Description – Serial Port 2 in RS-485 Mode (JCOM2)**

DATA +/-	This differential signal pair sends and receives serial data to the communication link. The mode of this differential signal pair is controlled through the RTS register of Serial Port 2. Set the RTS register of the Serial Port 2 to LOW for transmitting, HIGH for receiving.
----------	---

**3.7.21 Front Panel Connector (JFP)**

Signal	PIN		Signal
HWRST#	1	2	VCC5SBY
GND	3	4	GND
VCC5	5	6	VCC5
HDLED	7	8	GND
VCC5SBY	9	10	VCC5SBY
PWRBT	11	12	SUSLED
EXTSM#	13	14	VCC5
GND	15	16	SPKIN

1, 3	Reset SW
9, 11	Power SW
10, 12	Suspend LED
13, 15	Suspend SW

## User's Manual

**3.7.22 IrDA Connector (JIR)**

Signal	PIN
IRTX	5
GND	4
IRRX	3
NC	2
VCC	1

**3.7.23 Signal Description – IR Connector (JIR)**

IRRX	Infrared Receiver input
IRTX	Infrared Transmitter output

**3.7.24 Keyboard and PS/2 mouse connector (JKBMS)**

Signal	PIN		Signal
		4	NC
MCLK	7	3	MDAT
VCC	6	2	GND
KCLK	5	1	KDAT

**3.7.25 Signal Description – Keyboard and PS/2 Mouse Connector (JKBMS)**

KCLK	Bi-directional clock signal used to strobe data/commands from/to the PC-AT keyboard.
KDAT	Bi-directional serial data line used to transfer data from or commands to the PC-AT keyboard.
MCLK	Bi-directional clock signal used to strobe data/commands from/to the PS/2 mouse.
MDAT	Bi-directional serial data line used to transfer data from or commands to the PS/2 mouse.

**3.7.26 Miscellaneous Setting Connector (JMISC)**

Signal	PIN		Signal
CASEOPEN#	1	2	VTIN3
GND	3	4	THRMDN
VCC5	5	6	VCC5
BRIGHT	7	8	#MASTER
GND	9	10	GND

**3.7.27 Signal Description – JMISC Connector**

1, 3	Case open detection
5, 7, 9	LCD brightness setting
2,4	Thermal detection
6, 8, 10	CF Master/Slave setting <b>8-10 short (default: Master)</b>

## User's Manual

## 3.7.28 LVDS Connector (JLVDS)

Signal	PIN		Signal
VDDSAFE5	2	1	VDDSAFE3
VDDSAFE5	4	3	VDDSAFE3
DDCPDATA	6	5	DDCPCLK
GND	8	7	GND
YAP0	10	9	YAP1
YAM0	12	11	YAM1
GND	14	13	GND
YAP2	16	15	YAP3
YAM2	18	17	YAM3
GND	20	19	GND
YBP0	22	21	YBP1
YBM0	24	23	YBM1
GND	26	25	GND
YBP2	28	27	YBP3
YBM2	30	29	YBM3
GND	32	31	GND
CLKAP	34	33	CLKBP
CLKAM	36	35	CLKBM
GND	38	37	GND
RESERVED	40	39	RESERVED

## 3.7.29 Signal Description – LVDS Connector (JLVDS)

DDCPDATA	I/O CMOS	<b>Panel DDC Data:</b> This signal is used as the DDC data signal between the LFP and the GMCH.
DDCPCLK	I/O CMOS	<b>Panel DDC Clock:</b> This signal is used as the DDC clock signal between the LFP and the GMCH.
YAP	○ LVDS	<b>Channel A differential data pair 3:0 output (true):</b> 245-800 MHz.
YAM	○ LVDS	<b>Channel A differential data pair 3:0 output (compliment):</b> 245--800 MHz
YBP	○ LVDS	<b>Channel B differential data pair 3:0 output (true):</b> 245-800 MHz.
YBM	○ LVDS	<b>Channel B differential data pair 3:0 output (compliment):</b> 245- 800 MHz.
CLKAP	○ LVDS	<b>Channel A differential clock pair output (true):</b> 245-800 MHz
CLKAM	○ LVDS	<b>Channel A differential clock pair output (compliment):</b> 245- 800 MHz.
CLKAP	○ LVDS	<b>Channel B differential clock pair output (true):</b> 245-800 MHz
CLKAM	○ LVDS	<b>Channel B differential clock pair output (compliment):</b> 245- 800 MHz.

### 3.7.30 TMD5 Connector (JTMDS)

Signal	PIN		Signal
VCC5	2	1	TDC0#
GND	4	3	TDC0
NC	6	5	NC
NC	8	7	NC
HPDET	10	9	TDC1#
MDVIDATA	12	11	TDC1
MDVICLK	14	13	NC
GND	16	15	NC
TLC#	18	17	TDC2#
TLC	20	19	TDC2

### 3.7.31 Signal Description – TMD5 Connector (JTMDS)

TDC0, TDC0#	○	<b>DVI Data Channel 0 Outputs:</b> These pins provide the DVI differential outputs for data channel 0 (blue).
TDC1, TDC1#	○	<b>DVI Data Channel 1 Outputs:</b> These pins provide the DVI differential outputs for data channel 1 (green).
TDC2, TDC2#	○	<b>DVI Data Channel 2 Outputs:</b> These pins provide the DVI differential outputs for data channel 2 (red).
HPDET	I	<b>Hot Plug Detect (internal pull-down):</b> This input pin determines whether the DVI is connected to a DVI monitor. When terminated, the monitor is required to apply a voltage greater than 2.4 volts. Changes on the status of this pin will be relayed to the graphics controller via the P-OUT/TLDET* or GPIO (1)/TLDET* pin pulling low.
MDVIDATA	I/O	<b>DVO I2C Data:</b> This signal is used as the I2C_DATA for a digital display (i.e. TV-Out Encoder, TMD5 transmitter). This signal is tri-stated during a hard reset.
MDVICLK	I/O	<b>DVI DDC Clock:</b> This signal is used as the DDC clock for a digital display connector (i.e. primary digital monitor). This signal is tri-stated during a hard reset.
TLC, TLC#	○	<b>DVI Clock Outputs:</b> These pins provide the differential clock outputs for the DVI interface corresponding to data on TDC (0:2) outputs.

## User's Manual

**3.7.32 USB Connector (JUSB)**

Signal	PIN		Signal
	CH3	CH2	
VCC3	1	2	GND
D3-	3	4	GND
D3+	5	6	D2+
GND	7	8	D2-
GND	9	10	VCC2

**3.7.33 Signal Description – USB Connector (JUSB)**

D2+ / D2-	Differential bi-directional data signal for USB channel 2. Clock is transmitted along with the data using NRZI encoding. The signalling bit rate is up to 12 Mbs.
D3+ / D3-	Differential bi-directional data signal for USB channel 3. Clock is transmitted along with the data using NRZI encoding. The signalling bit rate is up to 12 Mbs.
VCC	5 V DC supply for external devices. Maximum load according to USB standard.

**3.7.34 PS/2 Keyboard & Mouse Connector (KB\_MS)**

Signal	PIN		Signal
MCLK	6		KCLK
VCC	4		GND
MDAT		2	KDAT
		1	

**3.7.35 Signal Description – PS/2 Keyboard & Mouse Connector**

KCLK	Bi-directional clock signal used to strobe data/commands from/to the PC-AT keyboard.
KDAT	Bi-directional serial data line used to transfer data from or commands to the PC-AT keyboard.
MCLK	Bi-directional clock signal used to strobe data/commands from/to the PS/2 mouse.
MDAT	Bi-directional serial data line used to transfer data from or commands to the PS/2 mouse.

**3.7.36 10/100 BASE-Tx Ethernet Connector (LAN1/LAN2)**

Signal	PIN
TXD+	1
TXD-	2
RXD+	3
NC	4
NC	5
RXD-	6
NC	7
NC	8

**3.7.37 Signal Description – 10/100Base-Tx Ethernet Connector**

TXD+ / TXD-	Ethernet 10/100Base-Tx differential transmitter outputs.
RXD+ / RXD-	Ethernet 10/100Base-Tx differential receiver inputs.

**3.7.38 10/100/1000 BASE-Tx Ethernet Connector (LAN2: 82540EM Optional)**

Signal	PIN
MDI0+	1
MDI0-	2
MDI1+	3
MDI2+	4
MDI2-	5
MDI1-	6
MDI3+	7
MDI3-	8

## User's Manual

**3.7.39 Signal Description – 10/100/1000Base-Tx Ethernet Connector**

MDI (0) +/-	Media Dependent Interface (0) 1000BASE-T: In MDI configuration, MDI (0)+/- corresponds to BI_DA+/-, and in MDI-X configuration, MDI (0) +/- corresponds to BI_DB+/-. 100BASE-TX: In MDI configuration, MDI (0)+/- is used for the transmit pair, and in MDI-X configuration, MDI (0) +/- is used for the receive pair. 10BASE-T: In MDI configuration, MDI (0)+/- is used for the transmit pair, and in MDI-X configuration, MDI (0) +/- is used for the receive pair.
MDI (1) +/-	Media Dependent Interface (1) 1000BASE-T: In MDI configuration, MDI (1)+/- corresponds to BI_DB+/-, and in MDI-X configuration, MDI (1) +/- corresponds to BI_DA+/-. 100BASE-TX: In MDI configuration, MDI (1)+/- is used for the receive pair, and in MDI-X configuration, MDI (1) +/- is used for the transmit pair. 10BASE-T: In MDI configuration, MDI (1)+/- is used for the receive pair, and in MDI-X configuration, MDI (1) +/- is used for the transmit pair.
MDI (2) +/-	Media Dependent Interface (2) 1000BASE-T: In MDI configuration, MDI (2) +/- corresponds to BI_DC+/-, and MDI-X configuration, MDI (2) +/- corresponds to BI_DD+/-. 100BASE-TX: Unused. 10BASE-T: Unused.
MDI (3) +/-	Media Dependent Interface (3) 1000BASE-T: In MDI configuration, MDI (3) +/- corresponds to BI_DD+/-, and MDI-X configuration, MDI (3) +/- corresponds to BI_DC+/-. 100BASE-TX: Unused. 10BASE-T: Unused.

**3.7.40 Parallel Port Connector (LPT)**

Signal	PIN		Signal
NC	26	13	SLCT
GND	25	12	PE
GND	24	11	BUSY
GND	23	10	ACK#
GND	22	9	PD7
GND	21	8	PD6
GND	20	7	PD5
GND	19	6	PD4
GND	18	5	PD3
SLIN#	17	4	PD2
INIT#	16	3	PD1
ERR#	15	2	PD0
AFD#	14	1	STB#

**3.7.41 DB25 Parallel Port Connector (LPT)**

Signal	PIN		Signal
STB#	1		
		14	AFD#
PD0	2		
		15	ERR#
PD1	3		
		16	INIT#
PD2	4		
		17	SLIN#
PD3	5		
		18	GND
PD4	6		
		19	GND
PD5	7		
		20	GND
PD6	8		
		21	GND
PD7	9		
		22	GND
ACK#	10		
		23	GND
BUSY	11		
		24	GND
PE#	12		
		25	GND
SLCT	13		

## User's Manual

**3.7.42 Signal Description – Parallel Port (LPT)**

The following signal description covers the signal definitions, when the parallel port is operated in standard centronic mode. The parallel port controller also supports the fast EPP and ECP modes.

PD [7:0]	Parallel data bus from PC board to printer. The data lines are able to operate in PS/2 compatible bi-directional mode.
SLIN#	Output line for detection of printer selection. This pin is pulled high internally.
SLCT	An active high input on this pin indicates that the printer is selected. This pin is pulled high internally.
STB#	An active low output is used to latch the parallel data into the printer. This pin is pulled high internally.
BUSY	An active high input indicates that the printer is not ready to receive data. This pin is pulled high internally.
ACK#	An active low input on this pin indicates that the printer has received data and is ready to accept more data. This pin is pulled high internally.
INIT#	Output line for the printer initialization. This pin is pulled high internally.
AFD#	An active low output from this pin causes the printer to auto feed a line after a line is printed. This pin is pulled high internally.
ERR#	An active low input on this pin indicates that the printer has encountered an error condition. This pin is pulled high internally.
PE#	An active high input on this pin indicates that the printer has detected the end of the paper. This pin is pulled high internally.

**3.7.43 System Fan Connector 1 (S\_FAN1)**

SIGNAL	PIN
GND	1
+12V	2
TAC	3

**3.7.44 System Fan Connector 2 (S\_FAN2)**

SIGNAL	PIN
GND	1
+12V	2
TAC	3

**3.7.45 Signal Description – System Fan Connector**

TAC	Fan speed monitor
-----	-------------------

**3.7.46 VGA Connector (VGA)**

Signal	PIN		Signal
		6	ANA-GND
RED	1	11	NC
		7	ANA-GND
GREEN	2	12	DDCDAT
		8	ANA-GND
BLUE	3	13	HSYNC
		9	VCC
NC	4	14	VSYNC
		10	DIG-GND
DIG-GND	5	15	DDCCLK

**3.7.47 Signal Description – VGA Connector (VGA)**

HSYNC	CRT horizontal synchronisation output.
VSYNC	CRT vertical synchronisation output.
DDCCLK	Display Data Channel Clock. Used as clock signal to/from monitors with DDC interface.
DDCDAT	Display Data Channel Data. Used as data signal to/from monitors with DDC interface.
RED	Analog output carrying the red colour signal to the CRT. For 75 $\Omega$ cable impedance.
GREEN	Analog output carrying the green colour signal to the CRT. For 75 $\Omega$ cable impedance.
BLUE	Analog output carrying the blue colour signal to the CRT. For 75 $\Omega$ cable impedance.

**3.7.48 IEEE1394 Port Connector (J1394/1394)**

Signal	PIN		Signal
XTPA0P	6	5	XTPA0M
XTPB0P	4	3	XTPB0M
GND	2	1	+12V

**3.7.49 Signal Description – IEEE1394 Port Connector (J1394/1394)**

XTPA0P	Port 1 Twisted Pair A Positive.
XTPA0M	Port 1 Twisted Pair A Negative.
XTPB0P	Port 1 Twisted Pair B Positive.
XTPB0M	Port 1 Twisted Pair B Negative.

## User's Manual

### 4. AWARD BIOS Setup

#### 4.1 Starting Setup

The AwardBIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the CMOS and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing <Del> immediately after switching the system on, or

By pressing the <Del> key when the following message appears briefly at the bottom of the screen during the POST (Power On Self Test).

Press DEL to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to.

Press F1 To Continue, DEL to enter SETUP

## 4.2 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item in the left hand
Right arrow	Move to the item in the right hand
Esc key	Main Menu -- Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
PgUp key	Increase the numeric value or make changes
PgDn key	Decrease the numeric value or make changes
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
(Shift) F2 key	Change color from total 16 colors. F2 to select color forward, (Shift) F2 to select color backward
F3 key	Calendar, only for Status Page Setup Menu
F4 key	Reserved
F5 key	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu
F6 key	Load the default CMOS value from BIOS default table, only for Option Page Setup Menu
F7 key	Load the default
F8 key	Reserved
F9 key	Reserved
F10 key	Save all the CMOS changes, only for Main Menu

**Table 1 : Legend Keys**

### 4.2.1 Navigating Through The Menu Bar

Use the left and right arrow keys to choose the menu you want to be in.

### 4.2.2 To Display a Sub Menu

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “➤” pointer marks all sub menus.

## User's Manual

### 4.3 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or the F1 key again.

### 4.4 In Case of Problems


If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AwardBIOS™ supports an override to the CMOS settings which resets your system to its defaults.

The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both Award and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

### 4.5 Main Menu

Once you enter the AwardBIOS™ CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and two exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

Note that a brief description of each highlighted selection appears at the bottom of the screen.



#### 4.5.1 Setup Items

The main menu includes the following main setup categories. Recall that some systems may not include all entries.

**4.5.1.1 Standard CMOS Features**

Use this menu for basic system configuration.

**4.5.1.2 Advanced BIOS Features**

Use this menu to set the Advanced Features available on your system.

**4.5.1.3 Advanced Chipset Features**

Use this menu to change the values in the chipset registers and optimize your system's performance.

**4.5.1.4 Integrated Peripherals**

Use this menu to specify your settings for integrated peripherals.

**4.5.1.5 Power Management Setup**

Use this menu to specify your settings for power management.

**4.5.1.6 PNP / PCI Configuration**

This entry appears if your system supports PnP / PCI.

**4.5.1.7 PC Health Status**

This entry appears your system Hardware Monitor Status

## User's Manual

### 4.5.1.8 Frequency / Voltage Control

Use this menu to specify your settings for frequency/voltage control.

### 4.5.1.9 Load Fail-Safe Defaults

Use this menu to load the BIOS default values for the minimal/stable performance for your system to operate.

### 4.5.1.10 Load Optimized Defaults

Use this menu to load the BIOS default values that are factory settings for optimal performance system operations. While Award has designed the custom BIOS to maximize performance, the factory has the right to change these defaults to meet their needs.

### 4.5.1.11 Supervisor / User Password

Use this menu to set User and Supervisor Passwords.

### 4.5.1.12 Save & Exit Setup

Save CMOS value changes to CMOS and exit setup.

### 4.5.1.13 Exit Without Save

Abandon all CMOS value changes and exit setup.

## 4.5.2 Standard CMOS Setup

The items in Standard CMOS Setup Menu are divided into 10 categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

### 4.5.2.1 Main Menu Selection

This table shows the selections that you can make on the Main Menu.

Item	Options	Description
Date	Month DD YYYY	Set the system date. Note that the 'Day' automatically changes when you set the date
Time	HH : MM : SS	Set the system time
IDE Primary Master	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Primary Slave	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Secondary Master	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Secondary Slave	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
Drive A Drive B	None 360K, 5.25 in 1.2M, 5.25 in 720K, 3.5 in 1.44M, 3.5 in 2.88M, 3.5 in	Select the type of floppy disk drive installed in your system
Boot Display	CRT LFP (LVDS) CRT+LFP(LVDS) EFP(PANEL-LINK) CRT+EFP	Select the Display Device
Panel Type	640x480 TFT 800x600 TFT 1024x768 TFT 1280x1024 TFT	Select the LCD panel type format
Halt On	All Errors No Errors All, but Keyboard All, but Diskette All, but Disk/Key	Select the situation in which you want the BIOS to stop the POST process and notify you
Base Memory	N/A	Displays the amount of conventional memory detected during boot up
Extended Memory	N/A	Displays the amount of extended memory detected during boot up
Total Memory	N/A	Displays the total memory available in the system

**Table 2 : Main Menu Selections**

## User's Manual

### 4.5.2.2 IDE Adapters

The IDE adapters control the hard disk drive. Use a separate sub menu to configure each hard disk drive.

Figure 2 shows the IDE primary master sub menu.

Use the legend keys to navigate through this menu and exit to the main menu. Use Table 3 to configure the hard disk.

Item	Options	Description
IDE HDD Auto-detection	Press Enter	Press Enter to auto-detect the HDD on this channel. If detection is successful, it fills the remaining fields on this menu.
IDE Primary Master	None Auto Manual	Selecting 'manual' lets you set the remaining fields on this screen. Selects the type of fixed disk. "User Type" will let you select the number of cylinders, heads, etc. Note: PRECOMP=65535 means NONE !
Capacity	Auto Display your disk drive size	Disk drive capacity (Approximated). Note that this size is usually slightly greater than the size of a formatted disk given by a disk checking program.
Access Mode	Normal LBA Large Auto	Choose the access mode for this hard disk
The following options are selectable only if the 'IDE Primary Master' item is set to 'Manual'		
Cylinder	Min = 0 Max = 65535	Set the number of cylinders for this hard disk.
Head	Min = 0 Max = 255	Set the number of read/write heads
Precomp	Min = 0 Max = 65535	**** <b>Warning:</b> Setting a value of 65535 means no hard disk
Landing zone	Min = 0 Max = 65535	****
Sector	Min = 0 Max = 255	Number of sectors per track

**Table 3 : Hard disk selections**

### 4.5.3 Advanced BIOS Features

This section allows you to configure your system for basic operation. You have the opportunity to select the system's default speed, boot-up sequence, keyboard operation, shadowing and security.

#### 4.5.3.1 Virus Warning

Allows you to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep.

Enabled	Activates automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table.
Disabled	No warning message will appear when anything attempts to access the boot sector or hard disk partition table.

#### 4.5.3.2 CPU L1 & L2 Cache

This item allows you to speed up memory access. However, it depends on CPU design.

Enabled	Enable cache
Disabled	Disable cache

#### 4.5.3.3 Hyper-Threading Technology

This item allows you to enable/disable CPU Hyper-Threading

#### 4.5.3.4 Quick Power On Self Test

This category speeds up Power On Self Test (POST) after you power up the computer. If it is set to Enable, BIOS will shorten or skip some check items during POST.

Enabled	Enable quick POST
Disabled	Normal POST

## User's Manual

### 4.5.3.5 First/Second/Third/Other Boot Device

The BIOS attempts to load the operating system from the devices in the sequence selected in these items.

Floppy	Floppy Device
LS120	LS120 Device
HDD-0	First Hard Disk Device
SCSI	SCSI Device
CDROM	CDROM Device
HDD-1	Secondary Hard Disk Device
HDD-2	Third Hard Disk Device
HDD-3	Fourth Hard Disk Device
ZIP100	ZIP-100 Device
USB-FDD	USB Floppy Device
USB-ZIP	USB ZIP Device
USB-CDROM	USB CDROM Device
USB-HDD	USB Hard Disk Device
LAN	Network Device
Disabled	Disabled any boot device

### 4.5.3.6 Boot Up Floppy Seek

Seeks disk drives during boot up. Disabling speeds boot up.

Enabled	Enable Floppy Seek
Disabled	Disable Floppy Seek

### 4.5.3.7 Boot Up NumLock Status

Select power on state for NumLock.

Enabled	Enable NumLock
Disabled	Disable NumLock

### 4.5.3.8 Gate A20 Option

Select if chipset or keyboard controller should control GateA20.

Normal	A pin in the keyboard controller controls GateA20
Fast	Lets chipset control GateA20

### 4.5.3.9 Typematic Rate Setting

Key strokes repeat at a rate determined by the keyboard controller. When enabled, the typematic rate and typematic delay can be selected.

The choice: Enabled/Disabled.

**4.5.3.10 Typematic Rate (Chars/Sec)**

Sets the number of times a second to repeat a key stroke when you hold the key down.

The choice: 6, 8, 10, 12, 15, 20, 24, or 30.

**4.5.3.11 Typematic Delay (Msec)**

Sets the delay time after the key is held down before it begins to repeat the keystroke.

The choice: 250, 500, 750, or 1000.

**4.5.3.12 Security Option**

Select whether the password is required every time the system boots or only when you enter setup.

System	The system will not boot and access to Setup will be denied if the correct password is not entered at the prompt.
Setup	The system will boot, but access to Setup will be denied if the correct password is not entered at the prompt.

**Note:** To disable security, select PASSWORD SETTING at Main Menu and then you will be asked to enter password. Do not type anything and just press <Enter>, it will disable security. Once the security is disabled, the system will boot and you can enter Setup freely.

**4.5.3.13 APIC Mode**

The BIOS supports versions 1.4 of the Intel multiprocessor specification. When enabled, The MPS Version 1.4 Control for OS can be activated.

The choice: Enabled/Disabled.

**4.5.3.14 OS Select for DRAM > 64MB**

Select the operating system that is running with greater than 64MB of RAM on the system.

The choice: Non-OS2, OS2.

**4.5.3.15 Report No FDD For WIN 95**

The original Windows95 requires the presence of a floppy. Unless the BIOS tells it to disregard the absence of the drive, it will generate an error message. For other operating systems as Win98 etc this field is without relevance.

No	Don't generate error message
Yes	Generate error message

## User's Manual

### 4.5.3.16 Small Logo (EPA) Show

This item allows you enabled/disabled the small EPA logo show on screen at the POST step,

Enabled	EPA Logo show is enabled
Disabled	EPA Logo show is disabled

### 4.5.4 Advanced Chipset Features

This section allows you to configure the system based on the specific features of the installed chipset. This chipset manages bus speeds and access to system memory resources, such as DRAM and the external cache. It also coordinates communications between the conventional ISA bus and the PCI bus. It must be stated that these items should never need to be altered. The default settings have been chosen because they provide the best operating conditions for your system. The only time you might consider making any changes would be if you discovered that data was being lost while using your system.

The first chipset settings deal with CPU access to dynamic random access memory (DRAM). The default timings have been carefully chosen and should only be altered if data is being lost. Such a scenario might well occur if your system had mixed speed DRAM chips installed so that greater delays may be required to preserve the integrity of the data held in the slower memory chips.

#### 4.5.4.1 DRAM Timing Selectable

This item allows you to select the DRAM timing value by SPD data or Manual by yourself. The choice: Manual, By SPD.

#### 4.5.4.2 System BIOS Cacheable

This feature is only valid when the system BIOS is shadowed. It enables or disables the caching of the system BIOS ROM at **F0000h-FFFFFh** via the L2 cache. This greatly speeds up accesses to the system BIOS. However, this does **not** translate into better system performance because the OS does not need to access the system BIOS much.

The Choice: Disabled,Enabled.

#### 4.5.4.3 Video BIOS Cacheable

This feature is only valid when the video BIOS is shadowed. It enables or disables the caching of the video BIOS ROM at **C0000h-C7FFFh** via the L2 cache. This greatly speeds up accesses to the video BIOS. However, this does **not** translate into better system performance because the OS bypasses the BIOS using the graphics driver to access the video card's hardware directly.

The Choice: Enabled, Disabled.

#### 4.5.4.4 Memory Hole At 15M-16M

Enabling this feature reserves 15MB to 16MB memory address space to ISA expansion cards that specifically require this setting. This makes the memory from 15MB and up unavailable to the system. Expansion cards can only access memory up to 16MB. The choice: Enable, Disable.

#### 4.5.4.5 Delayed Transaction

This feature is used to meet the latency of PCI cycles to and from the ISA bus. The ISA bus is much, much slower than the PCI bus. Thus, PCI cycles to and from the ISA bus take a longer time to complete and this slows the PCI bus down.

However, enabling **Delayed Transaction** enables the chipset's embedded 32-bit posted write buffer to support delayed transaction cycles. This means that transactions to and from the ISA bus are buffered and the PCI bus can be freed to perform other transactions while the ISA transaction is underway.

This option should be **enabled** for better performance and to meet PCI 2.1 specifications. Disable it only if your PCI cards cannot work properly or if you are using an ISA card that is not PCI 2.1 compliant.

The Choice: Enabled, Disabled.

#### 4.5.4.6 Delay Prior to Thermal

When your system temperature is higher, you can set the DRAM access time slowdown between 4 min – 32 min delay.

The choice: 4 Min, 8 Min, 16 Min, and 32 Min.

#### 4.5.4.7 AGP Aperture Size

Select the size of Accelerated Graphics Port (AGP) aperture. The aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation.

The Choice: 4MB, 8MB, 16MB, 32MB, 64MB, 128MB, 256MB

## User's Manual

### 4.5.5 Integrated Peripherals

#### 4.5.5.1 On-Chip Primary PCI IDE

The chipset contains a PCI IDE interface with support for two IDE channels. Select Enabled to activate the primary IDE interface. Select Disabled to deactivate this interface.

The choice: Enabled, Disabled.

#### 4.5.5.2 On-Chip Secondary PCI IDE

The chipset contains a PCI IDE interface with support for two IDE channels. Select Enabled to activate the secondary IDE interface. Select Disabled to deactivate this interface.

The choice: Enabled, Disabled.

#### 4.5.5.3 Primary/Secondary Master/Slave PIO

The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device.

The choice: Auto, Mode 0, Mode 1, Mode 2, Mode 3, or Mode 4.

#### 4.5.5.4 Primary/Secondary Master/Slave UDMA

Ultra DMA/33 implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 95 OSR2 or a third-party IDE bus master driver). If your hard drive and your system software both support Ultra DMA/33, select Auto to enable BIOS support.

The Choice: Auto, Disabled.

#### 4.5.5.5 USB Controller

This item allows you to set the USB Controller to Enabled/Disabled.

The choice: Enabled , Disabled.

#### 4.5.5.6 USB Keyboard Support

This item allows you to set the system's USB keyboard to Enabled/Disabled.

The choice: Enabled , Disabled.

#### 4.5.5.7 Init Display First

This item allows you to decide to active whether PCI Slot or AGP first.

The choice: PCI Slot, AGP/Onboard

#### 4.5.5.8 AC97 Audio

This item allows you to decide to enable/disable the 815 chipset family to support AC97 Audio.

The choice: Enabled , Disabled.

#### 4.5.5.9 IDE HDD Block Mode

Block mode is also called block transfer, multiple commands, or multiple sector read/write. If your IDE hard drive supports block mode (most new drives do), select Enabled for automatic detection of the optimal number of block read/writes per sector the drive can support.

The Choice: Enabled, Disabled.

#### 4.5.5.10 Onboard FDC Controller

Select Enabled if your system has a floppy disk controller (FDC) installed on the system board and you wish to use it. If you install and-in FDC or the system has no floppy drive, select Disabled in this field.

The Choice: Enabled, Disabled.

#### 4.5.5.11 Onboard Serial Port 1/Port2

Select an address and corresponding interrupt for the first and second serial ports.

The choice: 3F8/IRQ4, 2E8/IRQ3, 3E8/IRQ4, 2F8/IRQ3, Disabled.

#### 4.5.5.12 UART Mode

Select UART 2 mode as standard serial port or IR port.

The choice: IrDA , ASKIR, Normal

#### 4.5.5.13 UR2 Duplex Mode

Select the value required by the IR device connected to the IR port. Full-duplex mode permits simultaneous two-direction transmission. Half-duplex mode permits transmission in one direction only at a time.

The Choice: Half, Full.

#### 4.5.5.14 Onboard Parallel Port

Select a logical LPT port name and matching address for the physical parallel (printer) port.

The choice: 378H/IRQ7, 278H/IRQ5, 3BCH/IRQ7, Disabled.

## User's Manual

### **4.5.5.15 Onboard Parallel Mode**

Select an operating mode for the onboard parallel port. Select Compatible or Extended unless you are certain both your hardware and software support EPP or ECP mode.

The choice: SPP, EPP, ECP, ECP+EPP, Normal

### **4.5.5.16 ECP Mode Use DMA**

Select a DMA channel for the port.

The choice: 3, 1.

### **4.5.5.17 Parallel Port EPP Type**

Select EPP port type 1.7 or 1.9.

The choice: EPP1.7, EPP1.9.

### **4.5.5.18 Watch Dog Timer Select**

This option will determine watch dog timer.

The choice: Disabled, 10 ,20 ,30 ,40 Sec, 1,2,4 Min

## 4.5.6 Power Management Setup

The Power Management Setup allows you to configure your system to most effectively save energy while operating in a manner consistent with your own style of computer use.

### 4.5.6.1 ACPI Function

This item allows you to enable/disable the ACPI function.

The choice: Enable, Disable.

### 4.5.6.2 ACPI Suspend Type

This item will set which ACPI suspend type will be used.

The choice: S1(POS), S3(STR).S1&S3

### 4.5.6.3 Power Management

This category allows you to select the type (or degree) of power saving and is directly related to the following modes:

#### 1. HDD Power Down

There are three selections for Power Management, both of them have fixed mode settings.

Min. Power Saving	Minimum power management, HDD Power Down = 15 Min,
Max. Power Saving	Maximum power management, HDD Power Down = 1 Min,
User Defined	Allows you to set each mode individually. When not disabled, each of the ranges are from 1 min. to 1 hr. except for HDD Power Down which ranges from 1 min. to 15 min. and disable.

### 4.5.6.4 Video Off Method

This determines the manner in which the monitor is blanked.

V/H SYNC+Blank	This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.
Blank Screen	This option only writes blanks to the video buffer.
DPMS	Initial display power management signaling.

## User's Manual

### 4.5.6.5 Video Off In Suspend

This determines the manner in which the monitor is blanked.

The choice: No , Yes.

### 4.5.6.6 Suspend Type

Select the suspend type.

The choice: Stop Grant , Pwron suspend.

### 4.5.6.7 MODEM Use IRQ

This determines the IRQ in which the MODEM can use.

The choice: 3, 4, 5, 7, 9, 10, 11, or NA.

### 4.5.6.8 Suspend Mode

When enabled and after the set time of system inactivity,all devices except the CPU will be shut off.

The choice:1/2/4/8/12/20/30/40 Min , 1 Hour , Disabled.

### 4.5.6.9 HDD Power Down

When enabled and after the set time of system inactivity,the hard disk drive will be powered down while all other devices remain active.

The choice:1/2/3/4/5/6/7/8/9/10/11/12/13/14/15 Min , Disabled.

### 4.5.6.10 Soft-Off by PWRBTN

Pressing the power button for more than 4 seconds forces the system to enter the Soft-Off state when the system has "hung".(Only could working on ATX Power supply)

The choice: Delay 4 Sec, Instant-Off.

### 4.5.6.11 Wake Up by PCI Card

This will enable the system to wake up through PCI Card peripheral.

The Choice. Enable, Disabled.

### 4.5.6.12 Power On By Ring

This determines whether the system boot up if there's an incoming call from the Modem.

The Choice. Enable, Disabled.

**4.5.6.13 USB KB Wake-up From S3**

This option is used to enabled/disabled USB keyboard wake up with suspend to RAM.

The Choice. Enable, Disabled

**4.5.6.14 Resume By Alarm**

This function is for setting date and time for your computer to boot up.


**Reload Global Timer Events****4.5.6.15 Primary IDE 0/1,Secondary IDE 0/1,FDD,COM,LPT PORT,PCI PIRQ[A-D]#**

Reload Global Timer events are I/O events whose occurrence can prevent the system from entering a power saving mode or can awake the system from such a mode. In effect ,the system remain alert for anything which occurs to a device which is configured as Enabled ,even when the system is in a power down mode.

## User's Manual

### 4.5.7 PnP/PCI Configuration Setup

This section describes configuring the PCI bus system. PCI, or **P**ersonal **C**omputer **I**nterconnect, is a system which allows I/O devices to operate at speeds nearing the speed the CPU itself uses when communicating with its own special components. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.



#### 4.5.7.1 Reset Configuration Data

Normally, you leave this field Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the operating system cannot boot.

The choice: Enabled, Disabled.

#### 4.5.7.2 Resource Controlled by

The Award Plug and Play BIOS has the capacity to automatically configure all of the boot and Plug and Play compatible devices. However, this capability means absolutely nothing unless you are using a Plug and Play operating system such as Windows®95. If you set this field to "manual" choose specific resources by going into each of the sub menu that follows this field (a sub menu is preceded by a "➤").

The choice: Auto, Manual.

#### 4.5.7.3 IRQ Resources

When resources are controlled manually, assign each system interrupt a type, depending on the type of device using the interrupt.

#### 4.5.7.4 IRQ3/4/5/7/9/10/11/12/14/15 Assigned to

This item allows you to determine the IRQ assigned to the ISA bus and is not available to any PCI slot. Legacy ISA for devices compliant with the original PC AT bus specification, PCI/ISA PnP for devices compliant with the Plug and Play standard whether designed for PCI or ISA bus architecture.

The Choice: *Legacy ISA* and *PCI/ISA PnP*.

#### 4.5.7.5 PCI / VGA Palette Snoop

Leave this field at *Disabled*.

Choices are Enabled, Disabled.

## User's Manual

### 4.5.8 PC Health Status

**This section show the status of your CPU , Fan & System status.**

### 4.5.9 Frequency / Voltage Control

#### 4.5.9.1 Auto Detect PCI Clk

This item allows you to enable/disable auto detect PCI Clock.

The choice: Enable, Disable.

#### 4.5.9.2 CPU Host /PCI Clock, Spread Spectrum

These option allows you to set Host clock/Spread Spectrum into various types of frequencies.

.

#### 4.5.10 Load Fail-Safe Defaults

When you press <Enter> on this item you get a confirmation dialog box with a message similar to:



```
Load Fail-Safe Defaults <Y/N>? N
```

Pressing 'Y' loads the BIOS default values for the most stable, minimal-performance system operations.

#### 4.5.11 Load Optimized Defaults

When you press <Enter> on this item you get a confirmation dialog box with a message similar to:




```
Load Optimized Defaults <Y/N>? N
```

Pressing 'Y' loads the default values that are factory settings for optimal performance system operations.

## User's Manual

## 4.5.12 Supervisor / User Password Setting



You can set either supervisor or user password, or both of them. The differences between are:

**supervisor password:** can enter and change the options of the setup menus.

**user password:** just can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

ENTER PASSWORD:


Type the password, up to eight characters in length, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password. To disable a password, just press <Enter> when you are prompted to enter the password. A message will confirm the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

PASSWORD DISABLED.

When a password has been enabled, you will be prompted to enter it every time you try to enter Setup. This prevents an unauthorized person from changing any part of your system configuration. Additionally, when a password is enabled, you can also require the BIOS to request a password every time your system is rebooted. This would prevent unauthorized use of your computer. You determine when the password is required within the BIOS Features Setup Menu and its Security option (see Section 3). If the Security option is set to "System", the password will be required both at boot and at entry to Setup. If set to "Setup", prompting only occurs when trying to enter Setup.

#### 4.5.13 Exit Selecting

##### 4.5.13.1 Save & Exit Setup




Pressing <Enter> on this item asks for confirmation:



Pressing "Y" stores the selections made in the menus in CMOS – a special section of memory that stays on after you turn your system off. The next time you boot your computer, the BIOS configures your system according to the Setup selections stored in CMOS. After saving the values the system is restarted again.

## User's Manual

## 4.5.13.2 Exit Without Saving



Pressing <Enter> on this item asks for confirmation:



This allows you to exit Setup without storing in CMOS any change. The previous selections remain in effect. This exits the Setup utility and restarts your computer.

## 5. Driver Installation

### 5.1 Driver Installation for Ethernet Adapter

#### 5.1.1 Windows 9x

A driver for the PCI Fast Ethernet controller on board is included in the attached supporting CD-ROM. The driver for this adapter are denoted 'Intel GD82551ER PCI Fast Ethernet Adapter' and 'Intel Pro/100 VE Ethernet Controller'.


The best way to install the driver for the Ethernet controller is to use the plug and play system of Windows 9x. The following procedures illustrate how the installation can be done.

1. Start the control panel by clicking the '*Start*' button, click '*Settings*' and '*Control Panel*' from the sub-menu. Double click the '*System*' icon in the control panel as shown below.




- Double click the '*System*' icon (highlighted above).
- Select the '*Device Manager*' tab.



## User's Manual



2. Double click 'PCI Ethernet Controller'. This will show the following window. Click the 'Reinstall Driver' button.



3. Click the 'Next' button to run Add New Hardware wizard to install device driver.



## User's Manual

- Specify the location of network adapter and click 'Next' (see below).



Another PCI Ethernet Controller is Intel-82551ER, the driver location are show as below:



5. Click the 'Next' button.



Or



## User's Manual

6. Click the *Finish* button.



Or



7. Depending on the configuration, a request for the windows disks or CD-ROM may be necessary. Insert the disk / CD-ROM and click the 'OK' button. An entry of the directory for the files may then be required. After typing the path name, click the 'OK' button.
8. To complete the installation, reboot the computer by clicking the 'Yes' button in the window shown below.



9. After the system restarts, the network adapter should be installed. Protocols, clients etc. may now be installed for the network in use.

Further configuration of the adapter may be made in the 'Advanced' section of the driver properties. These options may be accessed through the 'Network' icon in the control panel (Select the network adapter, click the 'Properties' button and select the 'Advanced' tab).

## User's Manual


### 5.1.2 Windows 2000 , XP Ethernet Installation

A driver for the PCI Fast Ethernet controller on board is included in the attached supporting CD-ROM. The driver for this adapter are denoted 'Intel 82551ER PCI Fast Ethernet Adapter' and 'Intel Pro/100 VE Ethernet Adapter'.


1. Start the control panel by clicking the 'Start' button, click 'Settings' and 'Control Panel' from the sub-menu. Double click the 'System' icon in the control panel as shown below.



2. On the System properties window, click the 'Hardware' tab as shown below.




3. Click the 'Device Manager...' button to show the Device Manager.



## User's Manual

4. Double click 'Ethernet Controller'. This will show the following window. Click the 'Reinstall Driver' button.



5. Click the 'Next' button to run Update Device Driver Wizard.



6. Click the 'Next' button to continue run upgrade device driver wizard.



7. Select the 'Specify a location' check item, click the 'Next' button to continue.



## User's Manual


8. The directory for the drivers may now be entered or click the 'Browse...' button to select the directory. Click the 'OK' button to continue.



Or



9. After system search the driver, click the 'Next' button to continue upgrade driver.



Or



## User's Manual

10. If the system show the Digital Signature not Found message, Click 'Yes' to continue the driver installation



11. After system install to drivers, the follow windows should appear, click the 'Finish' button to finish the driver installation.




Or



## User's Manual

12. After finish the driver installation, system will return to Properties windows as shown below. Click the 'OK' button to return the Device Manager.



Or




## 5.2 Driver Installation for Display Adapter


### 5.2.1 Windows 9x

The following steps will install the display driver for the Intel 855GM display controller.

1. Click the 'Start' button on the task bar, select 'Run' and specify the location of Intel 855GM Video driver setup program. This should start the driver setup program as shown below:




2. Click the 'Next' as shown below.




## User's Manual


3. Click the 'Next' as shown below.




4. Click the 'Next' as shown below.



5. Click the 'Yes' as shown below.



6. Click the 'Finish' button to complete the driver setup.




## User's Manual

### 5.2.2 Windows 2000 or Windows XP Display Installation


A display driver for Windows 2000 and Windows XP is supplied with the system on the Supporting CD-ROM.

The driver installation may be performed by following steps shown below:


1. Click the '*Start*' button on the task bar, select '*Run*' and specify the location of Intel 855GM Video driver setup program. This should start the driver setup program as shown below:




2. Click the '*Next*' as shown below.



- Click the 'Next' as shown below.




- Click the 'Yes' as shown below.



## User's Manual

5. Click the '*Finish*' button to complete the driver setup.




### 5.3 Driver Installation for Audio Adapter


#### 5.3.1 Windows 9x, Windows 2000, Windows XP

The following steps will install the audio driver for the 'Intel 82801DB AC97 Audio ' controller, the board use VIA 1616 AC97 Codec.

1. Click the 'Start' button on the task bar, select 'Run' and specify the location of Intel AC97 Audio driver setup program. This should start the Audio driver setup program as shown below:




2. Select 'Next >' as shown below.




## User's Manual

3. Select '*Next >*' as shown below.




4. Click the '*Finish*' button to complete the driver setup.




## 5.4 Driver Installation for Intel 855 Chipset

The following steps show how to install the Intel 855 chipset driver.

1. Click the 'Start' button on the task bar, select 'Run' and specify the location of Intel 855 chipset driver setup program. This should start the Intel Chipset driver setup program as shown below:




2. Press 'Next' to continue installation.




## User's Manual

3. Press 'Next' to continue installation.



4. Click the 'Finish' button to complete the driver setup.



5. To complete the driver installation and start the driver services, please reboot the computer.

## **6. POST Messages**

During the Power On Self-Test (POST), if the BIOS detects an error requiring you to do something to fix, it will either sound a beep code or display a message.

If a message is displayed, it will be accompanied by:

PRESS F1 TO CONTINUE, CTRL-ALT-ESC OR DEL TO ENTER SETUP

### **6.1 POST Beep**

Currently there are two kinds of beep codes in BIOS. This code indicates that a video error has occurred and the BIOS cannot initialize the video screen to display any additional information. This beep code consists of a single long beep followed by two short beeps. The other code indicates that your DRAM error has occurred. This beep code consists of a single long beep repeatedly.

### **6.2 Error Messages**

One or more of the following messages may be displayed if the BIOS detects an error during the POST. This list includes messages for both the ISA and the EISA BIOS.

#### **6.2.1 CMOS BATTERY HAS FAILED**

CMOS battery is no longer functional. It should be replaced.

#### **6.2.2 CMOS CHECKSUM ERROR**

Checksum of CMOS is incorrect. This can indicate that CMOS has become corrupt. This error may have been caused by a weak battery. Check the battery and replace if necessary.

#### **6.2.3 DISK BOOT FAILURE, INSERT SYSTEM DISK AND PRESS ENTER**

No boot device was found. This could mean that either a boot drive was not detected or the drive does not contain proper system boot files. Insert a system disk into Drive A: and press <Enter>. If you assumed the system would boot from the hard drive, make sure the controller is inserted correctly and all cables are properly attached. Also be sure the disk is formatted as a boot device. Then reboot the system.

#### **6.2.4 DISKETTE DRIVES OR TYPES MISMATCH ERROR - RUN SETUP**

Type of diskette drive installed in the system is different from the CMOS definition. Run Setup to reconfigure the drive type correctly.

## User's Manual

### 6.2.5 DISPLAY SWITCH IS SET INCORRECTLY

Display switch on the motherboard can be set to either monochrome or color. This indicates the switch is set to a different setting than indicated in Setup. Determine which setting is correct, and then either turn off the system and change the jumper, or enter Setup and change the VIDEO selection.

### 6.2.6 DISPLAY TYPE HAS CHANGED SINCE LAST BOOT

Since last powering off the system, the display adapter has been changed. You must configure the system for the new display type.

### 6.2.7 EISA Configuration Checksum Error PLEASE RUN EISA CONFIGURATION UTILITY

The EISA non-volatile RAM checksum is incorrect or cannot correctly read the EISA slot. This can indicate either the EISA non-volatile memory has become corrupt or the slot has been configured incorrectly. Also be sure the card is installed firmly in the slot.

### 6.2.8 EISA Configuration Is Not Complete PLEASE RUN EISA CONFIGURATION UTILITY

The slot configuration information stored in the EISA non-volatile memory is incomplete.

Note: When either of these errors appear, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.

### 6.2.9 ERROR ENCOUNTERED INITIALIZING HARD DRIVE

Hard drive cannot be initialized. Be sure the adapter is installed correctly and all cables are correctly and firmly attached. Also be sure the correct hard drive type is selected in Setup.

### 6.2.10 ERROR INITIALIZING HARD DISK CONTROLLER

Cannot initialize controller. Make sure the cord is correctly and firmly installed in the bus. Be sure the correct hard drive type is selected in Setup. Also check to see if any jumper needs to be set correctly on the hard drive.

### 6.2.11 FLOPPY DISK CNTRLR ERROR OR NO CNTRLR PRESENT

Cannot find or initialize the floppy drive controller. make sure the controller is installed correctly and firmly. If there are no floppy drives installed, be sure the Diskette Drive selection in Setup is set to NONE.

### **6.2.12 Invalid EISA Configuration** **PLEASE RUN EISA CONFIGURATION UTILITY**

The non-volatile memory containing EISA configuration information was programmed incorrectly or has become corrupt. Re-run EISA configuration utility to correctly program the memory.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.

### **6.2.13 KEYBOARD ERROR OR NO KEYBOARD PRESENT**

Cannot initialize the keyboard. Make sure the keyboard is attached correctly and no keys are being pressed during the boot.

If you are purposely configuring the system without a keyboard, set the error halt condition in Setup to HALT ON ALL, BUT KEYBOARD. This will cause the BIOS to ignore the missing keyboard and continue the boot.

### **6.2.14 Memory Address Error at ...**

Indicates a memory address error at a specific location. You can use this location along with the memory map for your system to find and replace the bad memory chips.

### **6.2.15 Memory parity Error at ...**

Indicates a memory parity error at a specific location. You can use this location along with the memory map for your system to find and replace the bad memory chips.

### **6.2.16 MEMORY SIZE HAS CHANGED SINCE LAST BOOT**

Memory has been added or removed since the last boot. In EISA mode use Configuration Utility to reconfigure the memory configuration. In ISA mode enter Setup and enter the new memory size in the memory fields.

### **6.2.17 Memory Verify Error at ...**

Indicates an error verifying a value already written to memory. Use the location along with your system's memory map to locate the bad chip.

### **6.2.18 OFFENDING ADDRESS NOT FOUND**

This message is used in conjunction with the I/O CHANNEL CHECK and RAM PARITY ERROR messages when the segment that has caused the problem cannot be isolated.

### **6.2.19 OFFENDING SEGMENT:**

This message is used in conjunction with the I/O CHANNEL CHECK and RAM PARITY ERROR messages when the segment that has caused the problem has been isolated.

## User's Manual

### 6.2.20 PRESS A KEY TO REBOOT

This will be displayed at the bottom screen when an error occurs that requires you to reboot. Press any key and the system will reboot.

### 6.2.21 PRESS F1 TO DISABLE NMI, F2 TO REBOOT

When BIOS detects a Non-maskable Interrupt condition during boot, this will allow you to disable the NMI and continue to boot, or you can reboot the system with the NMI enabled.

### 6.2.22 RAM PARITY ERROR - CHECKING FOR SEGMENT ...

Indicates a parity error in Random Access Memory.

### 6.2.23 Should Be Empty But EISA Board Found PLEASE RUN EISA CONFIGURATION UTILITY

A valid board ID was found in a slot that was configured as having no board ID.

NOTE; When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

### 6.2.24 Should Have EISA Board But Not Found PLEASE RUN EISA CONFIGURATION UTILITY

The board installed is not responding to the ID request, or no board ID has been found in the indicated slot.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

### 6.2.25 Slot Not Empty

Indicates that a slot designated as empty by the EISA Configuration Utility actually contains a board.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

### 6.2.26 SYSTEM HALTED, (CTRL-ALT-DEL) TO REBOOT ...

Indicates the present boot attempt has been aborted and the system must be rebooted. Press and hold down the CTRL and ALT keys and press DEL.

**6.2.27 Wrong Board In Slot  
PLEASE RUN EISA CONFIGURATION UTILITY**

The board ID does not match the ID stored in the EISA non-volatile memory.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.

**6.2.28 FLOPPY DISK(S) fail (80) ® Unable to reset floppy subsystem.****6.2.29 FLOPPY DISK(S) fail (40) ® Floppy Type mismatch.****6.2.30 Hard Disk(s) fail (80) ® HDD reset failed****6.2.31 Hard Disk(s) fail (40) ® HDD controller diagnostics failed.****6.2.32 Hard Disk(s) fail (20) ® HDD initialization error.****6.2.33 Hard Disk(s) fail (10) ® Unable to recalibrate fixed disk.****6.2.34 Hard Disk(s) fail (08) ® Sector Verify failed.****6.2.35 Keyboard is locked out - Unlock the key.**

BIOS detect the keyboard is locked. P17 of keyboard controller is pulled low.

**6.2.36 Keyboard error or no keyboard present.**

Cannot initialize the keyboard. Make sure the keyboard is attached correctly and no keys are being pressed during the boot.

**6.2.37 Manufacturing POST loop.**

System will repeat POST procedure infinitely while the P15 of keyboard controller is pull low. This is also used for M/B burn in test.

**6.2.38 BIOS ROM checksum error - System halted.**


The checksum of ROM address F0000H-FFFFFFH is bad.


**6.2.39 Memory test fail.**

BIOS reports the memory test fail if the onboard memory is tested error.

User's Manual

6. Measurement Drawing





## User's Manual

### **Appendix A: BIOS Revisions**

**BIOS Rev.**

**New Features**

**Bugs/Problems Solved**

**Known Problems**

## Appendix B: System Resources

### Memory Map

The following table indicates memory map of ECM-5716 series. The address ranges specify the runtime code length.

Address Range	Description	Note
00000000 - 0009FFFF	System board	
000A0000 - 000BFFFF	PCI bus	
000A0000 - 000BFFFF	Intel(R) 82852/82855 GM/GME Graphics Controller	
000A0000 - 000DFFFF	PCI bus	
000CD400 - 000CFFFF	System board	
000DF000 - 000DFFFF	Ricoh R/RL/RT/RC/5C475(II), R5C520 or Compatible CardBus Controller	
000E0000 - 000EFFFF	System board	
000F0000 - 000F7FFF	System board	
000F8000 - 000FBFFF	System board	
000FC000 - 000FFFFF	System board	
00100000 - 1DFEFFFF	System board	
1DFF0000 - 1DFFFFFF	System board	
1E000000 - FEBFFFFF	PCI bus	
D8000000 - DFFFFFFF	Intel(R) 82852/82855 GM/GME Graphics Controller	
E0000000 - E7FFFFFF	Intel(R) 82852/82855 GM/GME Graphics Controller	
E8000000 - E801FFFF	Intel(R) 8255xER PCI Adapter	
E8024000 - E80247FF	OHCI Compliant IEEE 1394 Host Controller	
E8025000 - E8025FFF	Intel(R) 8255xER PCI Adapter	
E8026000 - E8026FFF	Ricoh R/RL/RT/RC/5C475(II), R5C520 or Compatible CardBus Controller	
E8027000 - E8027FFF	Intel(R) PRO/100 VE Network Connection	
E8100000 - E817FFFF	Intel(R) 82852/82855 GM/GME Graphics Controller	
E8180000 - E81FFFFF	Intel(R) 82852/82855 GM/GME Graphics Controller	
E8200000 - E82003FF	Intel(r) 82801DB/DBM USB 2.0 Enhanced Host Controller - 24CD	
E8201000 - E82011FF	VIA AC'97 Audio Codec (WDM)	
E8202000 - E82020FF	VIA AC'97 Audio Codec (WDM)	
FABFE000 - FEBDFFFF	Ricoh R/RL/RT/RC/5C475(II), R5C520 or Compatible CardBus Controller	
FEBFE000 - FEBFEFFF	Ricoh R/RL/RT/RC/5C475(II), R5C520 or Compatible CardBus Controller	
FEBFFC00 - FEBFFFFF	Intel(R) 82801DB Ultra ATA Storage Controller - 24CB	
FEC00000 - FECFFFFFF	System board	
FEE00000 - FEEFFFFFF	System board	
FFB00000 - FFB7FFFF	System board	
FFB80000 - FFBFFFFFF	Intel(r) 82802 Firmware Hub Device	

**Note:** The usage of these I/O addresses depends on the choices made in the Evaluate setup screen. The I/O addresses are fully usable for PCI interface if the corresponding on-board unit is removed from the board.

## User's Manual

## I/O – Map

Certain I/O addresses are subject to change during boot as PnP managers may relocate devices or functions. The addresses shown in the table are typical locations.

I/O Port	Description	Note
00000000 – 00000CF7	PCI bus	
00000000 - 0000000F	Direct memory access controller	
00000010 - 0000001F	Motherboard resources	
00000020 – 00000021	Programmable interrupt controller	
00000022 - 0000003F	Motherboard resources	
00000040 – 00000043	System timer	
00000044 - 0000005F	Motherboard resources	
00000060 – 00000060	Standard 101/102-Key or Microsoft Natural PS/2	
00000061 – 00000061	System speaker	
00000062 – 00000063	Motherboard resources	
00000064 – 00000064	Standard 101/102-Key or Microsoft Natural PS/2	
00000065 - 0000006F	Motherboard resources	
00000070 – 00000073	System CMOS/real time clock	
00000074 - 0000007F	Motherboard resources	
00000080 – 00000090	Direct memory access controller	
00000091 – 00000093	Motherboard resources	
00000094 - 0000009F	Direct memory access controller	
000000A0 - 000000A1	Programmable interrupt controller	
000000A2 - 000000BF	Motherboard resources	
000000C0 - 000000DF	Direct memory access controller	
000000E0 - 000000EF	Motherboard resources	
000000F0 - 000000FF	Numeric data processor	
0000170 – 0000177	Secondary IDE Channel	
00001F0 - 00001F7	Primary IDE Channel	
0000274 - 0000277	ISAPNP Read Data Port	
0000279 - 0000279	ISAPNP Read Data Port	
00002F8 - 00002FF	Communications Port (COM2)	
0000376 - 0000376	Secondary IDE Channel	
0000378 - 000037F	Printer Port (LPT1)	
00003B0 - 00003BB	Intel(R) 82852/82855 GM/GME Graphics Controller	
00003C0 - 00003DF	Intel(R) 82852/82855 GM/GME Graphics Controller	
00003F0 - 00003F5	Standard floppy disk controller	
00003F6 - 00003F6	Primary IDE Channel	
00003F7 - 00003F7	Standard floppy disk controller	
00003F8 - 00003FF	Communications Port (COM1)	
0000400 - 00004BF	Motherboard resources	
00004D0 - 00004D1	Motherboard resources	
0000500 - 000051F	Intel(R) 82801DB/DBM SMBus Controller - 24C3	
0000778 - 000077B	Printer Port (LPT1)	
0000A78 - 0000A7B	Motherboard resources	

I/O Port	Description	Note
00000B78 - 00000B7B	Motherboard resources	
00000BBC - 00000BBF	Motherboard resources	
00000D00 - 0000FFFF	PCI bus	
00000E78 - 00000E7B	Motherboard resources	
00000F78 - 00000F7B	Motherboard resources	
00000FBC - 00000FBF	Motherboard resources	
0000B000 - 0000B03F	Intel(R) 8255xER PCI Adapter	
0000B400 - 0000B43F	Intel(R) PRO/100 VE Network Connection	
0000C000 - 0000C01F	Intel(R) 82801DB/DBM USB Universal Host Controller - 24C2	
0000C400 - 0000C41F	Intel(R) 82801DB/DBM USB Universal Host Controller - 24C4	
0000C800 - 0000C81F	Intel(R) 82801DB/DBM USB Universal Host Controller - 24C7	
0000CC00 - 0000CC07	Intel(R) 82852/82855 GM/GME Graphics Controller	
0000D400 - 0000D4FF	VIA AC'97 Audio Codec (WDM)	
0000D800 - 0000D83F	VIA AC'97 Audio Codec (WDM)	
0000F000 - 0000F00F	Intel(R) 82801DB Ultra ATA Storage Controller - 24CB	
0000FE00 - 0000FEFF	Ricoh R/RL/RT/RC/5C475(II), R5C520 or Compatible CardBus Controller	
0000FF00 - 0000FFFF	Ricoh R/RL/RT/RC/5C475(II), R5C520 or Compatible CardBus Controller	

**Note:**

The usage of these I/O addresses depends on the choices made in the Evaluate setup screen. The I/O addresses are fully usable for PCI interface if the corresponding on-board unit is removed.

## User's Manual

### Interrupt Usage

The actual interrupt settings depend on the PnP handler, the table below indicates the typical settings.

Interrupt	Description	Note
(ISA)0	System timer	
(ISA)1	Standard 101/102-Key or Microsoft Natural PS/2 Keyboard	
(ISA)3	Communications port (COM2)	
(ISA)4	Communications port (COM1)	
(ISA)6	Standard floppy disk controller	
(ISA)8	System CMOS/Real time clock	
(ISA)9	Microsoft ACPI-Compliant System	
(PCI)11	Intel(R) 82801DB/DBM SMBus Controller - 24C3	
(PCI)12	PS/2 compatible mouse	
(PCI)13	Numeric data processor	
(PCI)14	Primary IDE Channel	
(PCI)15	Secondary IDE Channel	
(PCI)16	Intel(R) 82852/82855 GM/GME Graphics Controller	
(PCI)16	Intel(R) 82801DB/DBM USB Universal Host Controller - 24C2	
(PCI)16	Ricoh R/RL/RT/RC/5C475(II), R5C520 or Compatible CardBus Controller	
(PCI)17	OHCI Compliant IEEE 1394 Host Controller	
(PCI)17	Intel(R) 8255xER PCI Adapter	
(PCI)17	VIA AC'97 Audio Codec (WDM)	
(PCI)18	Intel(R) 82801DB/DBM USB Universal Host Controller - 24C7	
(PCI)19	Intel(R) 82801DB/DBM USB Universal Host Controller - 24C4	
(PCI)20	Intel(R) PRO/100 VE Network Connection	
(PCI)23	Intel(r) 82801DB/DBM USB 2.0 Enhanced Host Controller - 24CD	

#### Note:

1. The usage of these interrupts depends on the choices made in the Evaluate setup screen. The interrupts are fully useable for PCI interface if the corresponding on-board unit is removed.
2. These interrupt lines are managed by the PnP handler and are subject to change during system initialisation.

Disabling the hard disk controller in the Evaluate setup screen may not release the interrupt line.

**DMA-channel Usage**

<b>DMA-channel</b>	<b>Description</b>	<b>Note</b>
DMA2	Standard floppy disk controller	
DMA4	Direct memory access controller	

**Note:**

The usage of these DMA-channels depends on the choices made in the Evaluate setup screen. The DMA-channels are fully usable for PCI interface if the corresponding on-board unit is disabled in the setup screen.

## User's Manual

### Appendix C: AWARD BIOS POST Messages

During the Power on Self-Test (POST), if the BIOS detects an error requiring you to do something to fix, it will either sound a beep code or display a message.

If a message is displayed, it will be accompanied by:

PRESS F1 TO CONTINUE, CTRL-ALT-ESC OR DEL TO ENTER SETUP

#### POST Beep

Currently there are two kinds of beep codes in BIOS. This code indicates that a video error has occurred and the BIOS cannot initialize the video screen to display any additional information. This beep code consists of a single long beep followed by two short beeps. The other code indicates that your DRAM error has occurred. This beep code consists of a single long beep repeatedly.

#### Error Messages

One or more of the following messages may be displayed if the BIOS detects an error during the POST. This list includes messages for both the ISA and the EISA BIOS.

#### CMOS BATTERY HAS FAILED

CMOS battery is no longer functional. It should be replaced.

#### CMOS CHECKSUM ERROR

Checksum of CMOS is incorrect. This can indicate that CMOS has become corrupt. This error may have been caused by a weak battery. Check the battery and replace if necessary.

#### DISK BOOT FAILURE, INSERT SYSTEM DISK AND PRESS ENTER

No boot device was found. This could mean that either a boot drive was not detected or the drive does not contain proper system boot files. Insert a system disk into Drive A: and press <Enter>. If you assumed the system would boot from the hard drive, make sure the controller is inserted correctly and all cables are properly attached. Also be sure the disk is formatted as a boot device. Then reboot the system.

#### DISKETTE DRIVES OR TYPES MISMATCH ERROR - RUN SETUP

Type of diskette drive installed in the system is different from the CMOS definition. Run Setup to reconfigure the drive type correctly.

**DISPLAY SWITCH IS SET INCORRECTLY**

Display switch on the motherboard can be set to either monochrome or color. This indicates the switch is set to a different setting than indicated in Setup. Determine which setting is correct, and then either turn off the system and change the jumper, or enter Setup and change the VIDEO selection.

**DISPLAY TYPE HAS CHANGED SINCE LAST BOOT**

Since last powering off the system, the display adapter has been changed. You must configure the system for the new display type.

**EISA Configuration Checksum Error**

PLEASE RUN EISA CONFIGURATION UTILITY

The EISA non-volatile RAM checksum is incorrect or cannot correctly read the EISA slot. This can indicate either the EISA non-volatile memory has become corrupt or the slot has been configured incorrectly. Also be sure the card is installed firmly in the slot.

**EISA Configuration Is Not Complete**

PLEASE RUN EISA CONFIGURATION UTILITY

The slot configuration information stored in the EISA non-volatile memory is incomplete.

Note: When either of these errors appear, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
---

**ERROR ENCOUNTERED INITIALIZING HARD DRIVE**

Hard drive cannot be initialized. Be sure the adapter is installed correctly and all cables are correctly and firmly attached. Also be sure the correct hard drive type is selected in Setup.

**ERROR INITIALIZING HARD DISK CONTROLLER**

Cannot initialize controller. Make sure the cord is correctly and firmly installed in the bus. Be sure the correct hard drive type is selected in Setup. Also check to see if any jumper needs to be set correctly on the hard drive.

**FLOPPY DISK CNTRLR ERROR OR NO CNTRLR PRESENT**

Cannot find or initialize the floppy drive controller. make sure the controller is installed correctly and firmly. If there are no floppy drives installed, be sure the Diskette Drive selection in Setup is set to NONE.

## User's Manual

### Invalid EISA Configuration

#### PLEASE RUN EISA CONFIGURATION UTILITY

The non-volatile memory containing EISA configuration information was programmed incorrectly or has become corrupt. Re-run EISA configuration utility to correctly program the memory.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.

### KEYBOARD ERROR OR NO KEYBOARD PRESENT

Cannot initialize the keyboard. Make sure the keyboard is attached correctly and no keys are being pressed during the boot.

If you are purposely configuring the system without a keyboard, set the error halt condition in Setup to HALT ON ALL, BUT KEYBOARD. This will cause the BIOS to ignore the missing keyboard and continue the boot.

### Memory Address Error at ...

Indicates a memory address error at a specific location. You can use this location along with the memory map for your system to find and replace the bad memory chips.

### Memory parity Error at ...

Indicates a memory parity error at a specific location. You can use this location along with the memory map for your system to find and replace the bad memory chips.

### MEMORY SIZE HAS CHANGED SINCE LAST BOOT

Memory has been added or removed since the last boot. In EISA mode use Configuration Utility to reconfigure the memory configuration. In ISA mode enter Setup and enter the new memory size in the memory fields.

### Memory Verify Error at ...

Indicates an error verifying a value already written to memory. Use the location along with your system's memory map to locate the bad chip.

### OFFENDING ADDRESS NOT FOUND

This message is used in conjunction with the I/O CHANNEL CHECK and RAM PARITY ERROR messages when the segment that has caused the problem cannot be isolated.

### OFFENDING SEGMENT:

This message is used in conjunction with the I/O CHANNEL CHECK and RAM PARITY ERROR messages when the segment that has caused the problem has been isolated.

**PRESS A KEY TO REBOOT**

This will be displayed at the bottom screen when an error occurs that requires you to reboot. Press any key and the system will reboot.

**PRESS F1 TO DISABLE NMI, F2 TO REBOOT**

When BIOS detects a Non-maskable Interrupt condition during boot, this will allow you to disable the NMI and continue to boot, or you can reboot the system with the NMI enabled.

**RAM PARITY ERROR - CHECKING FOR SEGMENT ...**

Indicates a parity error in Random Access Memory.

**Should Be Empty But EISA Board Found**

PLEASE RUN EISA CONFIGURATION UTILITY

A valid board ID was found in a slot that was configured as having no board ID.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

**Should Have EISA Board But Not Found**

PLEASE RUN EISA CONFIGURATION UTILITY

The board installed is not responding to the ID request, or no board ID has been found in the indicated slot.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

**Slot Not Empty**

Indicates that a slot designated as empty by the EISA Configuration Utility actually contains a board.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

**SYSTEM HALTED, (CTRL-ALT-DEL) TO REBOOT ...**

Indicates the present boot attempt has been aborted and the system must be rebooted. Press and hold down the CTRL and ALT keys and press DEL.

## User's Manual

### Wrong Board In Slot

PLEASE RUN EISA CONFIGURATION UTILITY

The board ID does not match the ID stored in the EISA non-volatile memory.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

**FLOPPY DISK(S) fail (80) ® Unable to reset floppy subsystem.**

**FLOPPY DISK(S) fail (40) ® Floppy Type mismatch.**

**Hard Disk(s) fail (80) ® HDD reset failed**

**Hard Disk(s) fail (40) ® HDD controller diagnostics failed.**

**Hard Disk(s) fail (20) ® HDD initialization error.**

**Hard Disk(s) fail (10) ® Unable to recalibrate fixed disk.**

**Hard Disk(s) fail (08) ® Sector Verify failed.**

**Keyboard is locked out - Unlock the key.**

BIOS detect the keyboard is locked. P17 of keyboard controller is pulled low.

**Keyboard error or no keyboard present.**

Cannot initialize the keyboard. Make sure the keyboard is attached correctly and no keys are being pressed during the boot.

**Manufacturing POST loop.**

System will repeat POST procedure infinitely while the P15 of keyboard controller is pull low. This is also used for M/B burn in test.

**BIOS ROM checksum error - System halted.**

The checksum of ROM address F0000H-FFFFFFH is bad.

**Memory test fail.**

BIOS reports the memory test fail if the onboard memory is tested error.

**POST Codes**

<b>POST (hex)</b>	<b>Description</b>
CFh	Test CMOS R/W functionality.
C0h	Early chipset initialization: -Disable shadow RAM -Disable L2 cache (socket 7 or below) -Program basic chipset registers
C1h	Detect memory -Auto-detection of DRAM size, type and ECC. -Auto-detection of L2 cache (socket 7 or below)
C3h	Expand compressed BIOS code to DRAM
C5h	Call chipset hook to copy BIOS back to E000 & F000 shadow RAM.
0h1	Expand the Xgroup codes locating in physical address 1000:0
02h	Reserved
03h	Initial Superio_Early_Init switch.
04h	Reserved
05h	1. Blank out screen 2. Clear CMOS error flag
06h	Reserved
07h	1. Clear 8042 interface 2. Initialize 8042 self-test
08h	1. Test special keyboard controller for Winbond 977 series Super I/O chips. 2. Enable keyboard interface.
09h	Reserved
0Ah	1. Disable PS/2 mouse interface (optional). 2. Auto detect ports for keyboard & mouse followed by a port & interface swap (optional). 3. Reset keyboard for Winbond 977 series Super I/O chips.
0Bh	Reserved
0Ch	Reserved
0Dh	Reserved
0Eh	Test F000h segment shadow to see whether it is R/W-able or not. If test fails, keep beeping the speaker.
0Fh	Reserved
10h	Auto detect flash type to load appropriate flash R/W codes into the run time area in F000 for ESCD & DMI support.
11h	Reserved
12h	Use walking 1's algorithm to check out interface in CMOS circuitry. Also set real-time clock power status, and then check for override.
13h	Reserved
14h	Program chipset default values into chipset. Chipset default values are MODBINable by OEM customers.
15h	Reserved

## User's Manual

POST (hex)	Description
16h	Initial Early_Init_Onboard_Generator switch.
17h	Reserved
18h	Detect CPU information including brand, SMI type (Cyrix or Intel) and CPU level (586 or 686).
19h	Reserved
1Ah	Reserved
1Bh	Initial interrupts vector table. If no special specified, all H/W interrupts are directed to SPURIOUS_INT_HDLR & S/W interrupts to SPURIOUS_soft_HDLR.
1Ch	Reserved
1Dh	Initial EARLY_PM_INIT switch.
1Eh	Reserved
1Fh	Load keyboard matrix (notebook platform)
20h	Reserved
21h	HPM initialization (notebook platform)
22h	Reserved
23h	<ol style="list-style-type: none"> <li>1. Check validity of RTC value: e.g. a value of 5Ah is an invalid value for RTC minute.</li> <li>2. Load CMOS settings into BIOS stack. If CMOS checksum fails, use default value instead.</li> <li>3. Prepare BIOS resource map for PCI &amp; PnP use. If ESCD is valid, take into consideration of the ESCD's legacy information.</li> <li>4. Onboard clock generator initialization. Disable respective clock resource to empty PCI &amp; DIMM slots.</li> <li>5. Early PCI initialization: <ul style="list-style-type: none"> <li>-Enumerate PCI bus number</li> <li>-Assign memory &amp; I/O resource</li> <li>-Search for a valid VGA device &amp; VGA BIOS, and put it into C000:0.</li> </ul> </li> </ol>
24h	Reserved
25h	Reserved
26h	Reserved
27h	Initialize INT 09 buffer
28h	Reserved
29h	<ol style="list-style-type: none"> <li>1. Program CPU internal MTRR (P6 &amp; PII) for 0-640K memory address.</li> <li>2. Initialize the APIC for Pentium class CPU.</li> <li>3. Program early chipset according to CMOS setup. Example: onboard IDE controller.</li> <li>4. Measure CPU speed.</li> <li>5. Invoke video BIOS.</li> </ol>
2Ah	Reserved
2Bh	Reserved
2Ch	Reserved

POST (hex)	Description
2Dh	1. Initialize multi-language 1. Put information on screen display, including Award title, CPU type, CPU speed ....
2Eh	Reserved
2Fh	Reserved
30h	Reserved
31h	Reserved
32h	Reserved
33h	Reset keyboard except Winbond 977 series Super I/O chips.
34h	Reserved
35h	Reserved
36h	Reserved
37h	Reserved
38h	Reserved
39h	Reserved
3Ah	Reserved
3Bh	Reserved
3Ch	Test 8254
3Dh	Reserved
3Eh	Test 8259 interrupt mask bits for channel 1.
3Fh	Reserved
40h	Test 8259 interrupt mask bits for channel 2.
41h	Reserved
42h	Reserved
43h	Test 8259 functionality.
44h	Reserved
45h	Reserved
46h	Reserved
47h	Initialize EISA slot
48h	Reserved
49h	1. Calculate total memory by testing the last double word of each 64K page. 2. Program writes allocation for AMD K5 CPU.
4Ah	Reserved
4Bh	Reserved
4Ch	Reserved
4Dh	Reserved
4Eh	1. Program MTRR of M1 CPU 2. Initialize L2 cache for P6 class CPU & program CPU with proper cacheable range. 3. Initialize the APIC for P6 class CPU. 4. On MP platform, adjust the cacheable range to smaller one in case the cacheable ranges between each CPU are not identical.
4Fh	Reserved
50h	Initialize USB

## User's Manual

POST (hex)	Description
51h	Reserved
52h	Test all memory (clear all extended memory to 0)
53h	Reserved
54h	Reserved
55h	Display number of processors (multi-processor platform)
56h	Reserved
57h	1. Display PnP logo 2. Early ISA PnP initialization -Assign CSN to every ISA PnP device.
58h	Reserved
59h	Initialize the combined Trend Anti-Virus code.
5Ah	Reserved
5Bh	(Optional Feature) Show message for entering AWDFLASH.EXE from FDD (optional)
5Ch	Reserved
5Dh	1. Initialize Init_Onboard_Super_IO switch. 2. Initialize Init_Onboard_AUDIO switch.
5Eh	Reserved
5Fh	Reserved
60h	Okay to enter Setup utility; i.e. not until this POST stage can users enter the CMOS setup utility.
61h	Reserved
62h	Reserved
63h	Reserved
64h	Reserved
65h	Initialize PS/2 Mouse
66h	Reserved
67h	Prepare memory size information for function call: INT 15h ax=E820h
68h	Reserved
69h	Turn on L2 cache
6Ah	Reserved
6Bh	Program chipset registers according to items described in Setup & Auto-configuration table.
6Ch	Reserved
6Dh	1. Assign resources to all ISA PnP devices. 2. Auto assign ports to onboard COM ports if the corresponding item in Setup is set to "AUTO".
6Eh	Reserved
6Fh	1. Initialize floppy controller 2. Set up floppy related fields in 40:hardware.
70h	Reserved
71h	Reserved
72h	Reserved


POST (hex)	Description
73h	(Optional Feature) Enter AWDFLASH.EXE if : -AWDFLASH is found in floppy drive. -ALT+F2 is pressed
74h	Reserved
75h	Detect & install all IDE devices: HDD, LS120, ZIP, CDROM.....
76h	Reserved
77h	Detect serial ports & parallel ports.
78h	Reserved
79h	Reserved
7Ah	Detect & install co-processor
7Bh	Reserved
7Ch	Reserved
7Dh	Reserved
7Eh	Reserved
7Fh	1. Switch back to text mode if full screen logo is supported. -If errors occur, report errors & wait for keys -If no errors occur or F1 key is pressed to continue: ♦Clear EPA or customization logo.
80h	Reserved
81h	Reserved
82h	1. Call chipset power management hook. 2. Recover the text font used by EPA logo (not for full screen logo) 3. If password is set, ask for password.
83h	Save all data in stack back to CMOS
84h	Initialize ISA PnP boot devices
85h	1. USB final Initialization 2. NET PC: Build SYSID structure 3. Switch screen back to text mode 4. Set up ACPI table at top of memory. 5. Invoke ISA adapter ROMs 6. Assign IRQs to PCI devices 7. Initialize APM 8. Clear noise of IRQs.
86h	Reserved
87h	Reserved
88h	Reserved
89h	Reserved
90h	Reserved
91h	Reserved
92h	Reserved
93h	Read HDD boot sector information for Trend Anti-Virus code

## User's Manual

<b>POST (hex)</b>	<b>Description</b>
94h	<ol style="list-style-type: none"><li>1. Enable L2 cache</li><li>1. Program boot up speed</li><li>2. Chipset final initialization.</li><li>3. Power management final initialization</li><li>4. Clear screen &amp; display summary table</li><li>5. Program K6 write allocation</li><li>6. Program P6 class write combining</li></ol>
95h	<ol style="list-style-type: none"><li>1. Program daylight saving</li><li>1. Update keyboard LED &amp; typematic rate</li></ol>
96h	<ol style="list-style-type: none"><li>1. Build MP table</li><li>2. Build &amp; update ESCD</li><li>3. Set CMOS century to 20h or 19h</li><li>4. Load CMOS time into DOS timer tick</li><li>5. Build MSIRQ routing table.</li></ol>
FFh	Boot attempt (INT 19h)

## Appendix E: Audio / USB Daughter Board User's Guide

### Jumper & Connector Layout



### Jumper and Connector List

Connector		
Label	Function	Note
CN1, CN2	USB connector	
CN4	Line out connector	Phone Jack
CN5	Line in connector	Phone Jack
CN6	Mic in connector	Phone Jack
JP1	2.54mm USB connector 1	5 x 2 header, pitch 2.54mm
JP3	Audio connector	5 x 2 header, pitch 2.0mm
JP4	2.54mm USB 2.0 connector 2	5 x 2 header, pitch 2.54mm
JP5	2.0mm USB connector	5 x 2 header, pitch 2.0mm
JP6	Line out / Speaker out select	1-3, 2-4 Speaker out 3-5, 4-6 Line out (Default)
JP7	TV / Audio connector	8 x 2 header, pitch 2.54mm

## User's Manual

## Connector Definitions

## 2.54mm USB Connector (JP1)

GND	GND	D1+	D1-	VCC1	Signal
9	7	5	3	1	CH1
10	8	6	4	2	CH2
VCC2	D2-	D2+	GND	GND	Signal

**Note:**

**Wrong USB cable configuration with your USB devices might cause your USB devices damaged.**

## Audio Connector (JP3)

SPK R	Mic	Line-In R	AGND	Line-Out R	Signal
9	7	5	3	1	CH1
10	8	6	4	2	CH2
SPK L	Mic Bais	Line-In L	AGND	Line-Out L	Signal

## 2.54mm USB 2.0 Connector 2 (JP4)

NC	GND	D1+	D1-	VCC1	Signal
9	7	5	3	1	CH1
10	8	6	4	2	CH2
NC	GND	D2+	D2-	VCC2	Signal

## 2.0mm USB Connector (JP5)

GND	USBGND	D1+	D1-	VCC1	Signal
9	7	5	3	1	CH1
10	8	6	4	2	CH2
VCC2	D2-	D2+	USBGND	GND	Signal

## TV / Audio Connector (JP7)

TVGND	TVGND	GND	Line-In L	SPK L	Line-Out L	GND	Mic	Signal
15	13	11	9	7	5	3	1	CH1
16	14	12	10	8	6	4	2	CH2
COMP	Cout	Yout	Line-In R	SPK R	Line-Out R	GND	Mic Bais	Signal